

Service Manual



74CC45/02B/07B/UBL
74CC65/02B/07B/UBL

Compact disc player




TABLE OF CONTENTS

SECTION	PAGE
1. Technical specifications	2
2. Instructions for use	3
3. Warnings	4
4. Dismantling instructions	5
5. Block diagram	14
6. Wiring diagram	15
7. Circuit diagrams and printed boards	
7.1. Power supply	16
7.2. Key board	17
7.3. diagram	18
7.4. diagram	19
7.5. diagram	20
7.6. er panel solder side	21
7.7. er panel component side	22
7.8. agram	23
7.9. play circuit diagram	24
7.10. splay panel	25
7.11. adphone	26
8. Ser d Faultfinding guide	27
9. Exp ader & Parts list	28
10. Exp abinet & Mechanical Parts list	29
11. Electrical Parts list	30

marantz®

model CC45 - CC65

MARANTZ DESIGN AND SERVICE

Using superior design and selected high grade components, MARANTZ company has created the ultimate in stereo sound. Only **original MARANTZ parts** can insure that your MARANTZ product will continue to perform to the specifications for which it is famous.

Parts for your MARANTZ equipment are generally available at our National Marantz Subsidiary or Agent.

<p style="margin: 0;">MARANTZ EUROPE B.V. P.O. Box 80002 Building SFF 2 5600 JB Eindhoven The Netherlands Phone : +31-40-732241 Fax : +31-40-735578</p>

ORDERING PARTS

Parts can be ordered either by mail or by telex. In both cases, the correct part number has to be specified. The following information must be supplied to eliminate delays in processing your order:

1. Complete address
2. Complete part numbers and quantities required
3. Description of parts
4. Model number for which the part is required
5. Way of shipment
6. Signature: any order form or telex must be signed, otherwise such part order will be considered as null and void.

ADDRESSES

AUSTRALIA
MARANTZ AUSTRALIA
Figtree Drive
Australia Centre
Homebush, NSW 2140
AUSTRALIA

FINLAND
MARANTZ
Kuortanegatan 1
00520
Helsingfors 52
Finland

ITALY
MARANTZ ITALIANA SPA
Piazza IV Novembre 3
20124 Milano
Italy

NORWAY
MARANTZ
Postboks 7034
Assiden
3007 Drammen
Norway

SPAIN
MARANTZ SPAIN
Martinez Villergas 2
Apartado 2065
Madrid 28027
Spain

AUSTRIA
MARANTZ
Hietzinger Kai 137a
1130 Wien
Austria

FRANCE
MARANTZ FRANCE
4 Rue Bernard Palissy
92600 Asnières
France

JAPAN
MARANTZ JAPAN INC.
35-1, 7-chome, Sagamiono
Sagamihara-shi, Kanagawa
Japan

PORTUGAL
COREL
Av. da Liberdade
211-2 Esq.
1200 Lisboa
Portugal

SWEDEN
MARANTZ
Box 1324
17125 Solna
Sweden

BELGIUM
MARANTZ EUROPE B.V.
Div. Benelux
P.O.Box 80002
Building SFF 2
5600 JB Eindhoven
The Netherlands

GERMANY
MARANTZ GERMANY GmbH
Kleine Heide 12
Postfach 4802
Halle-Westfalen
Germany

KUWAIT
AL ALAMIAH ELECTRONICS
P.O.Box 8196
Salmiah
22052 Kuwait

SAUDI ARABIA
AL ALAMIAH ELECTRONICS
P.O.Box 5954
University Street
Riyadh 11432
Saudi Arabia

SWITZERLAND
MARANTZ SWITZERLAND
Postfach
8010 Zürich-Müllingen
Switzerland

CHILE
MARANTZ DIVISION OF
PHILIPS S.A.
Av.Santa Maria 0760
Casilla 2687
Santiago
Chile

GREAT BRITAIN
MARANTZ HiFi UK Ltd.
Kingsbridge House
Padbury Oaks
575-583 Bath Road
Longford Middlesex UB7 OEH,
U.K.

NETHERLANDS
MARANTZ EUROPE B.V.
Div. Benelux
P.O.Box 80002
Building SFF 2
5600 JB Eindhoven
The Netherlands

SOUTH AFRICA
MARANTZ S.A.
10 Bond Street
Randburg 2194
P.O. Box 7703
Johannesburg 2000
South Africa

TRADING
MARANTZ TRADING
P.O.Box 20008
Building SFF 2
5600 JB Eindhoven
The Netherlands

DENMARK
MARANTZ
Horsvinget 5
2630 Tastrup
Denmark

GREECE
ADAMCO ELECTR. SA
P.O.Box 21025
Hippocrates Str. 188
Athens 11471
Greece

MARANTZ AMERICA, INC.
440 MEDINAH ROAD
ROSELLE, ILLINOIS 60172 - 2330
USA
PHONE : 708-307-3100
FAX : 708-307-2687

All of the above locations are fully equipped to take care of your total service needs or can advise you. Because various countries have differing configuration requirements, it is necessary that you contact the service facility in your particular country. In the event that there is no service location listed for your country, please contact the nearest facility for the necessary assistance.

<p style="margin: 0;">In case of difficulties, do not hesitate to contact the Technical Department at above mentioned address.</p>
--

TECHNICAL SPECIFICATIONS

General

1.Mains voltage	/02B /07B /UBL	: 220-230V (+11%-10%) : 240V (+10%-12%) : 120V ($\pm 10\%$)
2.Mains frequency		: 50-60 Hz
3.Mains voltage selection		: see circuit diagram power supply
4.Power consumption mains, operated		: 10W

Line output

1.Number of channels		: 2
2.Output voltage		: 2 Vrms \pm 2 dB
3.Unbalance left-right		: max. 1,2 dB
4.Output resistance		: 1 k Ω
5.Amplitude linearity		: max. \pm 0.4 dB from 20 Hz to 20 kHz
6.Phase non-linearity		: \pm 5.0° from 20 Hz to 16 kHz
7.Out-band attenuation		: min 35 dB above 40 kHz
8.Signal to noise ratio		: min. 95 dB from 20 Hz to 20 kHz
9.Dynamic range (-60 dB)		: min. 85 dB from 20 Hz to 20 kHz
10.Total harmonic distortion + noise		: min. 80 dB from 20 Hz to 20 kHz
11.Intermodulation distortion		: min. 85 dB max. 1 kHz
12.Channel separation		: min. 85 dB from 20 Hz to 20 kHz
13.Automatic switched deemphasis with time constant 15/50 μ s		
14.Non linearity at -90 dB		: typical ± 1 dB

Variable headphone (low end)(only CC65)

1.Output voltage		: max. 5 Vrms \pm 2dB
2.Unbalance left-right		: max. \pm 1.2dB
3.Output resistance		: 120 Ω
4.Load impedance range		: 32 Ω to 600 Ω load
5.Output power		: 0 to 30 mW into 32 Ω load : 0 to 50 mW into 120 Ω load : 0 to 30 mW into 600 Ω load

Audio specs with 20 kHz/13th order Cauer filter 4822 395 30204

6.Signal to noise ratio(1 kHz)		: min. 90 dB(digital silence detection)
7.Dynamic range		: min. 75 dB (20 Hz -20 kHz)
8.Total harmonic distortion		: min. 70 dB (19 Hz - 20 kHz)
9.Channel separation		: min. 70 dB (1 kHz)(digital silence detection) : min. 65 dB (20 Hz - 20 kHz)(dig. sil. det.)

Dimensions and weight


1.Apparatus tray closed		: WxDxH 435 x 380 x 106 mm
2.Apparatus tray open		: WxDxH 435 x 500 x 106 mm
3.Weight		: 7 kg

Optical read-out system

1.Laser type		: Semiconductor AlGaAs
2.Wavelength		: 780 nm \pm 20 nm
3.Light output (c.w.)		: max. 0.5 mW

INSTRUCTIONS FOR USE INSTALLATION

3-1



POWER SUPPLY SETTING

- Check if the type plate on the rear of your changer indicates the correct supply voltage.
- If your mains supply voltage is different, consult your dealer or our Service Organisation.

SITING THE COMPACT DISC CHANGER

Free standing


- Always position the changer horizontally on a flat, firm surface.
- Allow a free space of at least 3 cm above the changer so as not to interfere with the cooling of the changer.

In an audio rack

- The changer can be sited in any desired position.

Stacked

- Site the changer preferably at the bottom or at the top.
- Never position the changer directly on top of a high-power amplifier, as such an amplifier gives off a substantial amount of heat.



CAUTION!

Use of controls or adjustments or performance of procedures other than those specified here in may result in hazardous radiation exposure.

CONNECTIONS

1 DIGITAL OUTPUT

For connecting the CD changer to e.g. a DCC deck or other digital equipment.

- Connect the DIGITAL OUTPUT socket to the socket DIGITAL IN of the other set.


For *digital recording* from the CD changer, connect the DIGITAL OUTPUT socket to the socket DIGITAL IN of the DCC recorder.

Use here a lead with one cinch plug on either end.



2 ANALOGUE OUTPUT

For the connecting cable to the amplifier.



- Insert a red plug into the 'R' socket and the other plug into the 'L' socket.
- Insert the two other plugs into the corresponding sockets of the CD or AUX input of your amplifier.

You can also use the TUNER or TAPE IN connection, but **never** the PHONO input!

3 REMOTE CONTROL

For connecting up the equipment when you are incorporating the changer in a HiFi system with its own remote control system.


4 Mains lead

WARNINGS

- Do not expose the equipment to rain or moisture.
- Do not remove the cover from the equipment.
- Do not insert anything into the equipment through the ventilation holes.
- Do not handle the mains lead with wet hands.

This unit meets the requirements of EC Recommendation 82/499.


FUNCTIONAL OVERVIEW



FRONT OF CHANGER

- 1 POWER** – Switching on and off.
- 2 1-0 digit buttons**
 - Selecting another track during play.
 - Selecting a track to start play with.
 - Selecting tracks when compiling a programme.
 - Selecting the recording time when making a tape recording (EDIT).
- 3 P (programme)** – Opening and closing the memory when compiling a programme.
- 4 C (cancel)**
 - Erasing a programme.
 - Erasing track numbers from a programme.
- 5 Display** – Informs you about the functioning of the changer.
- 6 DISC NUMBER**
 - Selecting another CD during play.
 - Selecting a CD to start play with.
 - Selecting CDs when compiling a programme.
- 7 OPEN/CLOSE** – Opening and closing the CD compartment.
- 8 Infra Red sensor** – Receives the signals from the remote control.
- 9 RECALL** – Checking a programme.
- 10 EDIT** – Activating the EDIT function when making a tape recording.
- 11 DISPLAY** – Selecting the information you want to see on the display.
- 12 <</>>>/>>>>**
 - Selecting another track during play.
 - Selecting a track to start play with.
 - Fast search to a particular passage during play.
 - Selecting the recording mode when making a tape recording.
 - Selecting the recording time when making a tape recording.
- 13 STOP**
 - Stopping play.
 - Erasing a programme.
- 14 PLAY**
 - Starting play.
 - Returning to the beginning of a track.
- 15 PAUSE** – Interrupting play.
- 16 RANDOM** – Playing in random order.
- 17 REPEAT** – Repeating play.
- 18 AMS** – Automatically playing the beginning of each track.

- 19 PEAK SEARCH** – Searching the loudest passage (peak) on a CD or in a programme when making a tape recording.
- 20 FADER** – Fading in and out during play.
- 21 PHONES** – Connecting headphones.
- 22 Level control** – Adjusting the volume when listening with headphones.
- 23 QUICK PLAY** – Immediate playing of a particular CD.
- 24 LOAD** – Rotating the turntable in the CD compartment when inserting CDs.



DISPLAY



RANDOM – Lights up when the tracks are played in random order.
 (OO) – Lights up when the changer receives a command from the remote control.

PROGRAM

- Flashes when a programme is being compiled.
- Lights up when a programme is being played.

REPEAT DISC – Lights up when you repeat a CD.

REPEAT – Lights up when you repeat all CDs or a programme from them.

1 - 5 CD number indicator

- Flashes when you switch the changer on.
- Indicates the number of CDs in the CD compartment.
- Indicates what CD is being played.

TRACK – Indicates:

- what track is being played;
- the number of tracks on a CD or in a programme.

TRACK TIME – Indicates the elapsed playing time of the track being played.

REM(aining) TRACK TIME – Indicates the remaining playing time of the track being played.

TOTAL REM(aining) TIME – Indicates the remaining playing time of a CD.

TOTAL TIME – Indicates the total playing time of a CD.

AUTOSPACE – Lights up when an extra pause is inserted between the different tracks (when making a synchronized recording).

PAUSE – Lights up when play is interrupted.

EDIT – Lights up when the player is put into the EDIT mode.

1-15 track number indicator – Shows the number of tracks on a CD.

+15 – Lights up when there are more than 15 tracks on a CD.

Display messages:

read

Lights up when a CD's contents list is being scanned.

no disc

Lights up when there are no CDs in the CD compartment.

no audio disc

Lights up when insert a non audio CD (CD-ROM, CD-I or CDV).

not possible

Lights up when you select a non-existent track number.

GO TO PLAY

Lights up if you try to activate a function for which you must first start play.


GO TO STOP

Lights up if you try to activate a function for which you must first stop play.

REMOTE CONTROL - GENERAL

The remote control can be used for operating the CD changer (keys on front) as well as for operating a Marantz HiFi system (keys at the rear).

REMOTE CONTROL - FRONT (CD changer functions)

**1 ▼ DISC ▲**

- Selecting another CD during play.
- Selecting a CD to start play with.
- Selecting CDs when compiling a programme.

2 RANDOM – Playing in random order.

3 REPEAT – Repeating play.

4 AMS – Automatically playing the beginning of each track.

5 OPEN/CLOSE – Opening and closing the CD compartment.

6 <<< and >>>

- Selecting another track during play.
- Selecting a track to start play with.
- Selecting the recording mode when making a tape recording.
- Selecting the recording time when making a tape recording.

▶

- Starting play.
- Returning to the beginning of a track.

<<< and >>>

- Fast search to a particular passage during play.

||

- Interrupting play.


■

- Stopping play.
- Erasing a programme.

7 ▼ VOLUME ▲ – Adjusting the sound level when the changer is connected via the ANALOGUE OUTPUT or the DIGITAL OUTPUT to an amplifier or HiFi system *without* its own remote control.

FUNCTIONAL OVERVIEW

REMOTE CONTROL - REAR (system functions)



General functions

- 1 **Source selection keys** – Selecting the required source.
- 2 **POWER** – Switching the selected source on and off (standby).
- 11 **▲ VOL(ume) ▼** – Adjusting the sound level.
- 12 **MUTE ▼** – Muting the sound from the loudspeakers.

Tuner functions (FM/MW)

- 4 **RECALL** – Tuning up.
- 5 **CANCEL** – Tuning down.
- 6 **DISPLAY** – Selecting mono or stereo reception.
- 7 – **◀◀ and ▶▶ +** – Selecting preset stations.
- 10 **1-0 digit buttons** – Selecting preset stations.

TV functions (TV)

- 4 **RECALL** – Selecting a next channel.
- 5 **CANCEL** – Selecting a previous channel.
- 6 **DISPLAY** – Language selection.
- 9 **EDIT** – Switching between VIDEO and TV input.
- 10 **FADER** – Selecting the Picture in Picture (PIP) function.

Laser Disc functions (LD)

- 8 **■** – Stopping play.
- ▶ – Starting play.
- || – Interrupting play.
- 9 **EDIT** – Selecting side A of a laser disc.
- 10 **FADER** – Selecting side B of a laser disc.
- 6 **DISPLAY** – Selecting the LD audio mode.
- 4 **RECALL** – Scanning forward.
- 5 **CANCEL** – Scanning backward.

Cassette deck/DCC functions (TAPE/DCC)

- 4 **RECALL** – Winding the tape.
- 5 **CANCEL** – Rewinding and winding the tape.
- 6 **DISPLAY** – Selecting the tape travel direction.
- 7 – **◀◀ and ▶▶ +** – Selecting a next or previous track.
- 8 **■** – Stopping play.
- ▶ – Starting play.
- || – Interrupting play.
- 9 **EDIT** – Selecting deck A of a double deck.
- 10 **FADER** – Selecting side B of a double deck.

CD functions (CD)

- 3 **PROG(ramme) MEMO** – Opening and closing the memory when compiling a programme.
- 4 **RECALL** – Checking a programme.
- 5 **CANCEL** – Erasing a programme.
- Erasing track numbers from a programme.
- 6 **DISPLAY** – Selecting the information you want to see on the display.
- 7 – **◀◀ and ▶▶ +** – Selecting another track during play.
- Selecting a track to start play with.
- Selecting the recording mode when making a tape recording.
- Selecting the recording time when making a tape recording.
- 8 **■** – Stopping play.
- Erasing a programme.
- ▶ – Starting play.
- Returning to the beginning of a track.
- || – Interrupting play.
- 9 **EDIT** – Activating the EDIT function when making a tape recording.
- 10 **1-0 digit buttons** – Selecting another track during play.
- Selecting a track to start play with.
- Selecting tracks when compiling a programme.
- Selecting the recording time when making a tape recording (EDIT).
- 13 **FADER** – Fading in and out during play.

Video recorder functions (VCR 1/VCR 2)



- 4 **RECALL** – Winding the tape.
- 5 **CANCEL** – Rewinding and rewinding the tape.
- 6 **DISPLAY** – Language selection.
- Selecting the VCR audio mode.
- 8 **■** – Stopping play.
- ▶ – Starting play.
- || – Interrupting play.
- 10 **1-0 digit buttons** – Setting the clock.

PLAYBACK

INSERTING THE CDs

NOTE! Use only audio CDs; no CD-ROM, CD-I or CDV.

- Press **POWER 1** to switch the changer on.
- The changer will now start CD detection to check how many CDs there are in the CD compartment. The turntable will rotate slowly until all positions (1 - 5) in the CD compartment have been checked.
- The position which is being checked is always shown on the display (*DISC X*).
- After CD detection the 1-5 CD number indicator will show the number of CDs in the CD compartment.
- Open the CD compartment by pressing **OPEN/CLOSE 7**.
- **OPEN** lights up.
- Insert the CDs, **printed side up**; use the **LOAD button 24** to rotate the turntable in the CD compartment.




- Close the compartment by pressing **OPEN/CLOSE 7**.
- **CLOSE** lights up. The changer will start CD detection again.

NOTE!


- CD detection may *never* be interrupted. If, during detection, you press any button, then the changer will stop detection and the display will give an incorrect indication of the number of CDs in the CD compartment.
- **Always** remove all CDs from the CD compartment if you want to transport the changer.

NORMAL PLAYBACK (PLAY)

- The display shows the number of the current CD.



- Press **PLAY 14** to start playback.
- **READ** lights up and play starts from the first available CD.
- The CD number indicator (1-5) always shows what CD is being played (▶ X) and the track number indicator (1-15) shows how many tracks are on the CD; when a track has been played, its number disappears.
- The track being played and its elapsed playing time are shown under **TRACK** and **TRACK TIME**. See 'CALLING UP INFORMATION ON THE DISPLAY' on page 11 if you wish to see other information on the display.




- Play will stop after all CDs have been played.
- Press **POWER 1** to switch the changer off.

NOTE!

- You can also press **PLAY 14** immediately after inserting the CDs; the compartment then closes automatically.
- Use the **PREFERRED POSITION** in the CD compartment if you wish to insert only *one* CD and then start play by pressing the **QUICK PLAY button 23**. Play will then start immediately with the inserted CD.
- You can interrupt playback by pressing **PAUSE 15**; **PAUSE** then lights up. Press **PLAY** or **PAUSE** to restart.
- If you press **PLAY during play**, the current track will start again from the beginning.
- You can stop playback by pressing **STOP 13**.
- If you press **OPEN/CLOSE 7 during play**, the CD compartment will open while play continues. The three CDs *outside* the changer may now be changed without playback being interrupted.

PLAYBACK



SELECTING ANOTHER TRACK DURING PLAY (1-0)

- Key in the desired track number (on the current CD); numbers consisting of two figures must be keyed in **within 2 seconds**.
- The music stops and a moment later the selected track begins to play.

NOT POSSIBLE lights up if you select a non-existent number. You can also select the number by using ◀◀/▶▶ or ▶▶/▶▶ **12** (press less than 0.5 seconds).

SELECTING ANOTHER CD DURING PLAY (DISC NUMBER)

- Key in the desired CD number.
- The music stops and a moment later the selected CD begins to play.

NOT POSSIBLE lights up if you select a non-existent number.

SEARCHING FOR A PASSAGE DURING PLAY (◀◀/▶▶ ▶▶/▶▶)

- Hold ◀◀/▶▶ **12** down to search backwards to the beginning.
- Hold ▶▶/▶▶ **12** down to search forwards to the end.

The searching speed is determined by how long a key is pressed:

- the first 2 seconds fairly slowly, with sound;
- then at the maximum speed, with no sound.

If you reach the end of the last track and release ▶▶/▶▶ **12**, play will resume a few seconds before the end of the CD.

STARTING WITH A PARTICULAR CD (DISC NUMBER)

- Key in the required CD number.
- If the CD compartment was open, it will now close.
- Play starts from the selected CD.

NOT POSSIBLE lights up if you select a non-existent number.

STARTING WITH A PARTICULAR TRACK (1-0)

- First select the number of the required CD using DISC NUMBER **6**.
- Then key in the required track number (numbers consisting of two figures must be keyed in **within 2 seconds**).
- If the CD compartment was open, it will now close.
- Play starts from the selected track.

You can also select the (track) number by using ◀◀/▶▶ or ▶▶/▶▶ **12** (press less than 0.5 seconds) and then pressing PLAY **14**.

NOT POSSIBLE lights up if you select a non-existent (track) number.

SCANNING CDs (AMS)

All CDs:

- Press AMS **18** before or during play.
- If the CD compartment was open, it will now close.
- *SCAN* lights up and the first 10 seconds of each track are played in turn (starting from the current track). 10 seconds are counted down each time under REM(aining) TRACK TIME.



- When the changer reaches a track which you wish to hear in full, press AMS again or PLAY **14**.


One CD:

- Select the number of the required CD using DISC NUMBER **6**.
- Press AMS **18**, **within the time** the CD number is flashing on the display.
- Now only the first 10 seconds of each track on the selected CD will be played in turn.

PLAYING IN RANDOM ORDER (RANDOM)

All CDs:

- Press RANDOM **16** before or during play.
- If the CD compartment was open, it will now close.
- *RANDOM* lights up and all the tracks are now played in a random order.




- If you press ▶▶/▶▶ **12**, you will select any one of the following tracks.
- Press RANDOM again if you wish to return to normal play.

NOTE!

If, during play, you open the CD compartment to change CDs (see 'NORMAL PLAYBACK' on page 9) then playback in random order will be cancelled. Playback will stop as soon as the last track of the current CD has been played (in normal order).

One CD:

- Select the number of the required CD using DISC NUMBER **6**.
- Press RANDOM **16**, **within the time** the CD number is flashing on the display.
- *DISC* and *RANDOM* light up; the tracks of the selected CD will now be played in a random order.




- If you press ▶▶/▶▶ **12**, you will select any one of the following tracks.
- If you press REPEAT **17**, the tracks will be repeated in a different order each time, although the first track will always be the same.
- When all tracks of the selected CD have been played, playback stops.
- Press RANDOM again if you wish to return to normal play.

REPEATING PLAY (REPEAT)

Repeating a CD:

- Press REPEAT **17** before or during playback of the CD.
- *REPEAT DISC* lights up; the CD will now be repeated continuously.




- Press REPEAT **twice** to stop the CD being repeated.

PLAYBACK

Repeating all CDs:

- Press REPEAT **17** twice before or during playback.
- *REPEAT* lights up; all CDs will now be repeated continuously.




- Press REPEAT again to stop the CDs being repeated.

ACTIVATING THE FADE- IN AND FADE-OUT FUNCTION (FADER)


NOTE!

The FADER function can be used if the changer is connected to the amplifier or the system via the ANALOGUE OUTPUT or the DIGITAL OUTPUT.

- During play press FADER **20**.
- The sound level will now gradually decrease (FADE OUT), after which the changer will go into the PAUSE mode.




- Press FADER again.
- Play continues and the sound level will increase again to the originally set level (FADE IN).



SEARCHING THE LOUDEST PASSAGE (PEAK SEARCH)

- In STOP mode, press PEAK SEARCH **19**.
- *SELECT DISC* lights up.
- Select the number of the required CD using DISC NUMBER **6**.
- The CD will now be scanned for the loudest passage (the peak).
- The display shows the track being scanned and its elapsed playing time.



- When the loudest passage has been found it will be repeated continuously (from 2 seconds before the peak until 2 seconds after the peak)

- You can now adjust your recording device.
- You can stop the scan by pressing STOP **13**: if you press PLAY **14**, the CD will be played from the beginning.

NOTE!


- When searching for the loudest passage in a programme (from one or more CDs) there is no need to enter the CD number(s).
- If you wish to record tracks from different CDs you have to repeat peak search for each CD.

CALLING UP INFORMATION ON THE DISPLAY (DISPLAY)

In STOP mode:

Text display

- After loading the CDs and closing the CD compartment, the display shows the number of the CD to be played (= default display in STOP mode).



During play:

1. Time display

- When you start play (from STOP mode), the display shows the elapsed playing time of the current track (= default display in PLAY mode).



- Press DISPLAY **11** whenever you want to know the remaining playing time of the current track (REM TRACK TIME).




- Press DISPLAY again if you wish to know the remaining playing time of the entire CD (TOTAL REM TIME).




Note - TOTAL REM(aining) TIME indication is *not* available in SHUFFLE mode.

- If you wish to know the total playing time of the entire CD you must go back to STOP mode *first and then* press DISPLAY.
- The display now shows the number of tracks and the total playing time of the current CD (TOTAL TIME).



2. Text display

- If you press DISPLAY again, you will switch to text display; the display shows the number of the current CD.




ADJUSTING THE SOUND LEVEL (▼ VOLUME ▲)


NOTE!

- Use the ▼ VOLUME ▲ keys (*front of remote control*) only if the changer is connected via the ANALOGUE OUTPUT or the DIGITAL OUTPUT to an amplifier or HiFi system *without* its own control.
- The setting chosen with ▼ VOLUME ▲ will be cancelled when the changer is switched off.

- Hold ▼ VOLUME **7** (*front of remote control*) pressed down.
- The output signal from the player will now decrease gradually.
- The successive steps are shown on the display.



- Release the key as soon as the required sound level is obtained.
- Hold VOLUME ▲ **7** (*front of remote control*) pressed down.
- The output signal will now increase again gradually to the maximum level.



- Release the key as soon as the required sound level is obtained.

PROGRAMMING

STORING A PROGRAMME (P and 1-0)

- By programming the changer you can play up to 30 tracks in any required sequence.
- *FULL* lights up if you exceed the maximum of 30 tracks.
- *NOT POSSIBLE* lights up if you select a non-existent CD number.
- *USE 0-9* lights up if you press **◀◀/▶▶ ▶▶/▶▶ 12** while programming.


- In STOP mode, press P (programme) **3** to open the memory.
- *SELECT DISC* lights up and **PROGRAM** starts flashing.
- Select the number of the first required CD using **DISC NUMBER 6**.
- Key in the required track numbers of the selected CD using the 1-0 digit buttons **2**.
- Every track number you enter in this way will be included immediately in the programme.
- The display always shows the number of tracks and the playing time of your programme.



- If you wish to store tracks from another CD, you should first enter the number of the CD.
- Press P to quit the PROGRAM mode.
- Press **PLAY 14** to play the programme.

CHECKING THE PROGRAMME (RECALL)

- Press **RECALL 9** prior to, during or after programmed play.
- *REV* lights up and all CD and track numbers appear in the programmed sequence on the display.
- Under **TRACK TIME** you will see the playing time of each track.



NO PROG will light up if no track numbers have yet been stored.

With **RECALL** you can proceed more rapidly to the next block of information.

PLAYING THE PROGRAMME (PLAY)

- Press **PLAY 14**.
- Playback starts with the first number of the programme.

The **EDIT 10**, **P(rogramme) 3** and **C(lear) 4** and **PEAK SEARCH 19** buttons *cannot* be used during programmed play. Search for a particular passage is only possible within the track being played.

ERASING A PROGRAMME (STOP, C or OPEN/CLOSE)


- In PLAY mode:**
- Press **OPEN/CLOSE 7** or **STOP 13** (twice).

- In STOP mode:**
- Press **OPEN/CLOSE 7**, **C 4** or **STOP 13**.

- The programme has now been erased.

ERASING A TRACK FROM A PROGRAMME (C)

- Press **RECALL 9** before or after programmed play (STOP mode).
- All CD and track numbers appear in the programmed sequence on the display.
- Press **C (cancel) 4** as soon as the number you wish to erase appears.
- The number has now been erased.
- The display shows the remaining number of tracks and the remaining programme time for a few seconds.



NO PROG will light up if no track numbers have yet been stored and if you have not pressed **RECALL** first before cancelling.

EDIT

The EDIT function has two recording modes in which you can store the recording time of the tape in the changer memory.

EDIT NORMAL – The changer will determine which tracks fit on each side of the tape and will stop after the last track. The tracks will be recorded in the order in which they appear on the CD(s).

EDIT OPTIMAL – The changer now calculates the combination of tracks that will optimize the use of available recording time.

NOTE!

- The EDIT function *cannot* be used for CDs containing more than 30 tracks.
- The **▼ VOLUME ▲** keys on the remote control (**7 front and 11 rear**) may not be used during recording as they affect the strength of the signal from the changer.

BEFORE RECORDING

Preparation:

- A programme to be recorded, must be stored in advance. See 'PROGRAMMING' on page 12.
- If required you can search the loudest passage and adjust your recording device. See 'SEARCHING THE LOUDEST PASSAGE (PEAK SEARCH)' on page 11. This can also be done *after* selecting the recording mode and the recording time. See below.
- Press **EDIT 10** to activate the EDIT mode.
- **EDIT** lights up and *SELECT DISC* appears on the display.
- Select the number of the required CD using **DISC NUMBER 6**. When recording a programme there is no need to enter the CD number(s).
- *NOT POSSIBLE* lights up if you select a non-existent disc number.

Selecting the recording mode:


- The display shows *EDIT* (= EDIT NORMAL which is the default setting).
- With **◀◀/▶▶ ▶▶/▶▶ 12** you can now select *OPT(imal)*, *CANCEL* or *EDIT (NORMAL)* again.
- The display shows *OPT(imal)*, *CANCEL*, or *EDIT* again.
- Press **EDIT 10** to store the required recording mode (NORMAL or OPTimal).
- If you select *CANCEL*, the EDIT mode will be cancelled and the changer will go back to STOP mode.
- As soon as you have stored the recording mode the display shows *C90* (default setting).

Selecting the recording time:


- As soon as you have stored the recording mode the display shows *C90* (default setting).
- With **◀◀/▶▶ ▶▶/▶▶ 12** you can now select the required recording time: *C100*, *C105*, *C120*, *C30*, *C45*, *C60*, *C75* or *C90*.
- Other recording times can be selected using the 1-0 digit buttons **2**; in EDIT NORMAL mode the recording time must be at least equal to the playing time of the first track on the first CD or in the programme. In EDIT OPTimal mode the recording time must be at least equal to the playing time of the shortest track on the CD(s) or in the programme.
- *NOT POSSIBLE* lights up if you select a 'wrong' time.
- Press **EDIT 10** to store the required recording time.
- The CD changer will now go back to STOP mode.
- You can now record the CD or the programme.

RECORDING

- Press **PLAY 14**.
- Playback starts with the selected CD (or with the first track of the programme).
- The display shows the elapsed playing time of the current track.
- Press **DISPLAY 11** to switch to other display information.
- The number of tracks for side A and their playing time are shown on the display.



- After the last track that fits on side A of the tape, the CD changer will go into PAUSE mode.
- *PAUSE* lights up.
- The track number indicator shows which tracks fit onto side B of the tape. Under **TRACK** you will see the number of the first track to be recorded.



- Turn the tape over or select the tape travel direction for side B.
- Press **PAUSE 15**.
- The remaining tracks will now be played.
- After the last track play will stop; *EDIT CANCELLED* lights up.

NOTE!

- As soon as you press **PLAY 14** the other changer functions will temporarily be switched off to prevent the recording being interfered with; *EDIT ACTIVE* lights up if you press one of the other buttons during recording.
- You can quit the EDIT mode by pressing **STOP 13**; *EDIT CANCELLED* then lights up.
- *EDIT NOT POSSIBLE* lights up if you try to record a CD containing more than 30 tracks.
- Should the CD or the programme be longer than the *total* recording time of the tape, play will stop after the last track that fits onto side B of the tape.
- Should the first track of the first CD or the programme be longer than one side of the tape (= the entered recording time divided by two), then *EDIT NOT POSSIBLE* will light up. You will now have to enter another recording time.

ADDITIONAL INFORMATION

SYNCHRONIZED RECORDING


- Make sure that the changer is connected via the REMOTE CONTROL sockets to the REMOTE CONTROL IN (RC 5 IN) sockets of the Marantz cassette deck.
- Set the changer to the EDIT mode.
- Select the required recording time (see: 'EDIT' on page 13).
- Select the \curvearrowright (auto reverse) mode (if available) on the cassette deck
- Set the TIMER switch (if available) on the deck to 'PLAY/SYNC REC' position.
- Press REC PAUSE on the deck.
- The cassette deck will go into REC PAUSE mode (= synchronized recording mode).
- Press PLAY on the CD changer.
- Recording starts and after 4 seconds play starts at the beginning of the CD or the programme.
- After each track an extra pause of 4 seconds (AUTO SPACE) will be inserted.
- AUTOSPACE lights up.
- If you record a programme from different CDs the cassette deck will go into PAUSE mode every time the CD changer selects a new CD in the CD compartment. As soon as playback of the new CD starts, the deck will continue the recording.
- After the last track that fits on side A of the tape, the CD changer will go into PAUSE mode.
- As soon as the CD changer receives a command from the cassette deck, playback starts with the first track for side B. You may also press PAUSE **15** to restart play.
- Synchronized recording will stop after the last track of the CD or the programme.

NOTE!

- As soon as you start recording, the other changer functions will temporarily be switched off to prevent the recording being interfered with; *EDIT ACTIVE* lights up if you press one of the other buttons during play/recording.
- You can stop playback/recording by pressing STOP **13**.

LISTENING WITH HEADPHONES (PHONES)


- Connect headphones with a 6.3 mm jack plug to the PHONES socket **21**.
- The sound level is adjusted with control **22**.



MAINTENANCE

The CDs

- Never write on the printed side of a CD.
- Do not attach any stickers to the CD.
- Keep the shiny surface of the disc clean. Use a soft lint-free cloth and always wipe the disc in a straight line from centre to edge.
- Never use cleaning agents for conventional records.
- Detergents or abrasive cleaning agents should not be used either.



The changer

- A chamois leather slightly moistened with water is sufficient for cleaning the changer.
- Do not use cleaning agents containing alcohol, spirits, ammonia or abrasives.

RECYCLING

Please observe the local regulations regarding the disposal of packing materials, exhausted batteries and old equipment.

1. All redundant packaging material has been omitted. We have done our utmost to make the packaging easy separable into three mono-materials:
 - cardboard (box)
 - expandable polystyrene (buffer)
 - polyethylene (bags, protective foam sheet)
2. Your set consists of materials which can be recycled if disassembled by a specialized company.
3. Do not dispose of exhausted batteries with your household waste.
4. **Note:** Switching off the standby mode overnight will save energy.

TECHNICAL DATA

Typical Audio Performance

Frequency range:2 Hz - 20 kHz
 Amplitude linearity:0.2 dB (20 Hz - 20 kHz)
 Dynamic range:>96 dB
 Signal-to-noise ratio:>110 dB
 Channel separation:>102 dB
 Total harmonic distortion:<.0025 %
 D/A conversion: Bitstream conversion (96 x oversampling, 1 bit), in differential mode
 Audio output level:2 V_{rms}
 Impedance PHONES socket:8 - 1000 ohms

Power supply

Mains voltage and frequency: see the type plate on the rear of the changer
 Power consumption:10 W
 Safety requirements:IEC 65

Cabinet

Material/finish:metal and polystyrene with decorative trim
 Dimensions (w x h x d):435 x 106 x 380 mm
 Weight:7 kg approx.

Subject to modification

This Compact Disc changer complies with radio interference requirements as laid down in EC regulations.

TROUBLE SHOOTING

If a fault occurs, run through the points listed below before taking your changer for repair. If the fault remains, try to clear it by **switching the changer off and on again**. If this also fails to help, consult your dealer. **Under no circumstances should you repair the changer yourself as this will invalidate the guarantee!**

SYMPTOM	POSSIBLE CAUSE	REMEDY
- Playback does not start or interruption of playback.	- The current CD has been loaded upside down. - No CDs inserted. - The current CD is badly scratched or dirty. - Moisture condensation on the lens.	• Reload the CD, label side up. • Insert the CDs, label side up. • Clean the CD with a soft, lint-free cloth. • Leave the CD changer in a warm environment until the moisture evaporates.
- Sound skips (at the same part).	- The current CD is dirty.	• Clean the CD with a soft, lint-free cloth.
- The current CD skips tracks.	- The CD is damaged or dirty.	• Replace or clean the CD.
- Playback does not start from the first track (of the current CD).	- P (programme) or RANDOM activated.	• Switch off RANDOM or clear programme.
- No sound or bad sound.	- Loose or wrong connections. - Strong magnetic fields near the CD changer.	• Check connections. • Find another place for the unit or change connections.
- No sound or bad sound on headphones.	- Level control set to - position. - Headphones plug is dirty.	• Set level control. • Clean plug.
- Volume is too low.	- Sound level has been adjusted too low with the ▼ VOLUME ▲ on the remote control.	• Adjust sound level.
- Remote control does not function.	- Batteries are empty.	• Replace the batteries.
- Remote control commands are not properly received	- The distance between remote control and CD changer is larger than 10 metres.	• Reduce the distance between remote control and CD changer.

GB WARNING

All ICs and many other semi-conductors are susceptible to electrostatic discharges (ESD). Careless handling during repair can reduce life drastically.
When repairing, make sure that you are connected with the same potential as the mass of the set via a wrist wrap with resistance. Keep components and tools also at this potential.

F ATTENTION

Tous les IC et beaucoup d'autres semi-conducteurs sont sensibles aux décharges statiques (ESD). Leur longévité pourrait être considérablement écourtée par le fait qu'aucune précaution n'est prise à leur manipulation.
Lors de réparations, s'assurer de bien être relié au même potentiel que la masse de l'appareil et enfiler le bracelet serti d'une résistance de sécurité.
Veiller à ce que les composants ainsi que les outils que l'on utilise soient également à ce potentiel.

D WARNUNG

Alle ICs und viele andere Halbleiter sind empfindlich gegen elektrostatische Entladungen (ESD).
Unvorsorgfältige Behandlung bei der Reparatur kann die Lebensdauer drastisch vermindern. Sorgen sie dafür, dass Sie im Reparaturfall über ein Pulsarmband mit Widerstand mit dem Massepotential des Gerätes verbunden sind. Halten Sie Bauteile und Hilfsmittel ebenfalls auf diesem Potential.

NL WAARSCHUWING

Alle IC's en vele andere halfgeleiders zijn gevoelig voor electrostatische ontladingen (ESD).
Onzorgvuldig behandelen tijdens reparatie kan de levensduur drastisch doen verminderen. Zorg ervoor dat u tijdens reparatie via een polsband met weerstand verbonden bent met hetzelfde potentiaal als de massa van het apparaat.
Houd componenten en hulpmiddelen ook op ditzelfde potentiaal.

I AVVERTIMENTO

Tutti IC e parecchi semi-conduttori sono sensibili alle scariche statiche (ESD).
La loro longevità potrebbe essere fortemente ridatta in caso di non osservazione della più grande cauzione alla loro manipolazione.
Durante le riparazioni occorre quindi essere collegato allo stesso potenziale che quello della massa dell'apparecchio tramite un braccialetto a resistenza.
Assicurarsi che i componenti e anche gli utensili con quali si lavora siano anche a questo potenziale.

ESD**GB**

Safety regulations require that the set be restored to its original condition and that parts which are identical with those specified be used.

NL

Veiligheidsbepalingen vereisen, dat het apparaat in zijn oorspronkelijke toestand wordt teruggebracht en dat onderdelen, identiek aan de gespecificeerde worden toegepast.

F

Les normes de sécurité exigent que l'appareil soit remis à l'état d'origine et que soient utilisées les pièces de rechange identiques à celles spécifiées.

D

Bei jeder Reparatur sind die geltenden Sicherheitsvorschriften zu beachten. Der Originalzustand des Geräts darf nicht verändert werden für Reparaturen sind Original-Ersatzteile zu verwenden.

I

Le norme di sicurezza esigono che l'apparecchio venga rimesso nelle condizioni originali e che siano utilizzati pezzi di ricambio identici a quelli specificati.

S Varning!

Osynlig laserstrålning när apparaten är öppnad och spärrenär urkopplad.
Betrakta ej strålen.

SF Varo!

Avatussa laitteessa ja suojalukituksen ohitettaessa olet alttiina näkymättömälle lasersäteilylle. Älä katso säteeseen!

DK Adverse!

Usynlig laserstråling ved åbning. Undgå udsættelse for stråling.

CAUTION

Invisible laser radiation when open.
Avoid exposure to beam.

DANGER

Invisible laser radiation when open.
Avoid direct exposure to beam


**CLASS 1
LASER PRODUCT**

3127 110 03420

DISMANTLING INSTRUCTIONS
DEMOUNTING OF COVER

5


5



HAS.104.3

PULL OUT OF TRAY
DEMOUNTING OF TRAYFRONT
DEMOUNTING OF DECODER PANEL

NOTE: Before demounting decoder panel
remove backplate.




HAS.1044

PULL OUT OF FLEXFOIL
DEMOUNTING OF FRONT

7


7



PULL OUT OF TRAY

8

8





A. "PULL" OUT TRAY



HAS.1046




DEMOUNTING OF CARROUSEL
DEMOUNTING OF CDM

9




9





SERVICING HINTS

In the set chip components have been applied. For disassembly and assembly of chip components see the figure below.



27 012C12

SERVICE TOOLS

Audio signal disc	4822 397 30184
Disc without errors (test disc 5) + disc with DO errors, black spots and fingerprints (test disc 5A)	4822 397 30096
Disc (65 min 1kHz) without pause	4822 397 30155
Max. diameter disc (58.0 mm)	4822 397 60141
Torx screwdrivers	
Set (straight)	4822 395 50145
Set (square)	4822 395 50132
13th order filter	4822 395 30204

SERVICE HINT ABOUT PHOTOTRANSISTOR 7701


The disc detection does not work when the decoder panel is demounted and when external light falls on the phototransistor.

This can be prevented by covering the transistor with a piece of paper or a cloth.

SERVICING HINTS



SERVICE POSITION OF TRAY


- Pull out tray and place it horizontally on the frame.
 - Reconnect the flexfoil.
 - Power on. Wait until discnumber "1" or "2" is on its preferred position.
 - Press stop.
 - Power off.
 - Load disc (on the preferred position).
 - Go to service mode 0.
 - Press play: wait until the disc is in the playposition.
 - Now it is possible to place the tray vertically on the frame while playing.
 - In this position measurements can be done on the Servo Panel.
- Please: do not touch the disc selection buttons, the shuffle button and the load button.



ASSEMBLY OF THE CARROUSEL

Turn camwheel (Exploded View item 116) until the conduction pin is in line with the rotary table of the CDM and the axis of the carousel, or until the conduction pin is close to the CDM. The CDM is now in the highest position (Play position). Mount the carousel with the discnumber "1" to the CDM.









ABBREVIATIONS











ACK	Acknowledge signal display(active LOW)
BCK	Bit clock input of BCC-DAC TDA1549
CARMOT	Carrousel motor
CARSW	Carrousel switch
CFLG	correction flag output
CL	interface clock input line
CL11	11.2896 MHz clock output
CL16	16.9344 MHz system clock output
CLA	4.2336 MHz microprocessor clock out put
CLO	Clock output
CRIN	crystal/resonator input
CROUT	crystal/resonator output
D1-D4	Central diode input of TDA1301
D1-D5	Photodiode signals from CDM12 mechanism
DA	interface data I/O line
DACCL	Bit clock output of CD6 decoder SAA7345
DACDA	Data output of CD6 decoder SAA7345
DACWS	Word select output of CD6 decoder SAA7345
DATA	serial data output/Data input of BCC-DAC TDA1549
DISPOS	Disc position
DISRES	RESET display
DOBM	Digital AUDIO output
ESI	Enhanced System Intelligence
FO	Focus actuator output
FOC+	+Connection of focus actuator
FOC-	Ground connection of focus actuator
HF	High-Frequency signal to decoder input
HFIN	comparator signal input
HFREF	comparator common-mode input
I.R.	Infra red receiver remote control
IREF	Reference current output
ISLICE	current feedback from data slicer
LDON	Laser drive on
LOAD SW	Load switch
MISC	general purpose DAC output
MOTO1,2	motor output 1,2
NRST	Reset input
OTD	Off track detector
PORE	power-on reset enable input(active low)
R1-R2	Satellite diode signal input
RA	Radial actuator output
RAB	interface R/W and acknowledge input
RAD+	+Connection of radial actuator
RAD-	Ground connection of radial actuator
SCK	CLOCK display
SCLK	serial bit clock output
SDAT	Serial data
SDAT0	DATAIN display
SDAT1	DATAOUT display
SDIS	Select display
SICL	Serial interface clock
SIDA	Serial interface data
SILD	Serial interface load
SL	Sledge output
SL OUT	+Connection of sledge motor
SLEDGE SW	Sledge switch of CDM12 mechanism
V1-5	Versatile input pins
VOL	Left channel output
VOR	Right channel output
WCLK	Word clock output
WS	Word select input of BCC-DAC TDA1549
XTLI	Oscillator input
XTLO	Oscillator output
XTLR	Oscillator reference

BLOCK DIAGRAM












POWER SUPPLY CIRCUIT DIAGRAM



POWER SUPPLY PANEL COMPONENT SIDE




POWER SUPPLY PANEL SOLDER SIDE



TRAN:


POWER SUPPLY PANEL SOLDER SIDE

9504 A 3	9001 B 1	6560 B 2	6505 A 1	6501 A 1	2544 B 4	2507 A 2	2503 A 2	1543 A 4	1503 A 2	1005 C 1
9505 A 3	9501 B 3	6561 B 2	6506 A 2	6502 A 1	2560 B 2	2508 A 1	2504 A 1	2500 A 1	1540 B 3	1500 B 4
9506 B 3	9502 B 3	6562 B 1	6507 B 2	6503 A 2	3560 B 2	2509 A 1	2505 A 1	2501 A 1	1541 B 3	1501 B 3
9503 A 3	7500 A 1	6508 B 2	6504 A 1	6500 A 1	2510 B 2	2506 A 2	2502 A 1	1542 A 4	1502 A 3	




TRANSFORMER CONNECTIONS


/00 /02 /07 VERSIONS



/17 VERSIONS




/01 VERSIONS



KEYBOARD CIRCUIT DIAGRAM


17



17



KEYBOARD PANEL


1405 B12 1439 B13 1441 B14 1443 B9 1445 B6 1447 B5 1449 B3 1451 B9 1453 B7 6425 B13 6427 B10 9001 C8
1438 B13 1440 B11 1442 B8 1444 B10 1446 B4 1448 B2 1450 B2 1452 B8 1454 B6 6426 C13 9000 B11 9002 B6






SERVO PANEL
COMPONENT SIDE

1802 A 3	1845 A 5	2809 B 2	2819 A 4	2829 B 3	2839 A 1	3801 B 2	3811 A 3	3822 A 4	3833 B 4	3843 B 2	3854 B 1	4858 C 3	4899 A 4	7823 C 2	9807 C 3	9819 C 3	9830 B 4	1840 C 6
1803 B 5	2800 B 2	2810 A 2	2820 A 3	2830 B 3	2840 B 2	3802 A 2	3812 B 2	3824 A 3	3834 B 3	3844 B 3	3855 C 1	4890 B 4	5801 B 3	7824 B 2	9808 A 3	9820 C 4	9831 B 4	1841 C 6
1804 A 5	2801 B 2	2811 B 2	2821 A 4	2831 B 4	2841 B 1	3803 B 2	3813 B 2	3825 A 3	3835 C 3	3845 C 1	4850 C 3	4891 B 4	5802 B 2	7825 C 3	9810 A 3	9821 C 4	9832 B 5	1842 B 6
1806 A 5	2802 B 2	2812 B 2	2822 A 4	2832 B 4	2842 C 2	3804 A 2	3814 A 2	3826 A 4	3836 C 4	3846 C 1	4851 B 3	4892 A 3	7800 A 2	9800 C 1	9811 A 3	9822 C 4	9833 A 5	
1811 B 4	2803 A 2	2813 A 3	2823 A 4	2833 A 4	2843 C 2	3805 B 3	3815 C 3	3827 B 1	3837 B 4	3847 B 1	4852 C 3	4893 C 4	7801 B 3	9801 B 1	9812 A 3	9823 C 4	9834 B 5	
1812 A 1	2804 A 2	2814 B 2	2824 A 4	2834 C 2	2856 A 4	3806 A 3	3816 A 3	3828 A 4	3838 A 5	3849 B 2	4853 B 3	4894 B 3	7802 A 4	9802 A 1	9813 A 1	9824 C 4	9835 B 4	
1820 C 5	2805 B 2	2815 A 2	2825 A 3	2835 C 2	2896 C 3	3807 A 2	3817 A 3	3829 A 4	3839 C 3	3850 C 2	4854 B 3	4895 A 1	7803 B 1	9803 A 2	9815 A 4	9825 C 4	9836 B 5	
1821 C 2	2806 A 2	2816 A 2	2826 A 3	2836 A 2	2897 B 3	3808 A 2	3818 A 4	3830 A 3	3840 B 2	3851 C 2	4855 A 4	4896 B 2	7820 B 1	9804 A 2	9816 B 3	9827 C 4	9837 A 3	
1830 A 4	2807 B 2	2817 A 4	2827 C 3	2837 A 2	2898 B 3	3809 B 2	3820 B 3	3831 B 3	3841 B 3	3852 C 2	4856 A 4	4897 C 3	7821 B 2	9805 B 2	9817 B 4	9828 B 4	9838 B 2	
1831 A 4	2808 A 2	2818 A 4	2828 B 3	2838 A 2	2899 A 1	3810 A 3	3821 A 4	3832 C 3	3842 B 2	3853 C 2	4857 B 4	4898 A 4	7822 C 2	9806 C 3	9818 C 3	9829 B 4	---	



SOLDER SIDE



1840 C 6	9830 B 4	9819 C 3	9807 C 3	7823 C 2	4899 A 4	48
1841 C 6	9831 B 4	9820 C 4	9808 A 3	7824 B 2	5801 B 3	48
1842 B 6	9832 B 5	9821 C 4	9810 A 3	7825 C 3	5802 B 2	48
	9833 A 5	9822 C 4	9811 A 3	9800 C 1	7800 A 2	48
	9834 B 5	9823 C 4	9812 A 3	9801 B 1	7801 B 3	48
	9835 B 4	9824 C 4	9813 A 1	9802 A 1	7802 A 4	48
	9836 B 5	9825 C 4	9815 A 4	9803 A 2	7803 B 1	48
	9837 A 3	9827 C 4	9816 B 3	9804 A 2	7820 B 1	48
	9838 B 2	9828 B 4	9817 B 4	9805 B 2	7821 B 2	48
	---	9829 B 4	9818 C 3	9806 C 3	7822 C 2	48




SOLDER SIDE


3 1	4858 C 3	4899 A 4	7823 C 2	9807 C 3	9819 C 3	9830 B 4	1840 C 6
1	4890 B 4	5801 B 3	7824 B 2	9808 A 3	9820 C 4	9831 B 4	1841 C 6
3	4891 B 4	5802 B 2	7825 C 3	9810 A 3	9821 C 4	9832 B 5	1842 B 6
3	4892 A 3	7800 A 2	9800 C 1	9811 A 3	9822 C 4	9833 A 5	
3	4893 C 4	7801 B 3	9801 B 1	9812 A 3	9823 C 4	9834 B 5	
3	4894 B 2	7802 A 4	9802 A 1	9814 A 3	9824 C 4	9835 B 4	
3	4895 A 1	7803 B 3	9803 A 2	9815 A 4	9825 C 4	9836 B 5	
3	4896 B 2	7804 B 1	9804 A 2	9816 B 3	9827 C 4	9837 A 3	
3	4897 C 3	7821 B 2	9805 B 2	9817 B 4	9828 B 4	9838 B 2	
3	4898 A 4	7822 C 2	9806 C 3	9818 C 3	9829 B 4	----	

1840 C 6	9830 B 4	9819 C 3	9807 C 3	7823 C 2	4899 A 4	4858 C 3	3854 B 1	3843 B 2	3833 B 4	3822 A 4	3811 A 3	3801 B 2	2839 A 1	2829 B 3	2819 A 4	2809 B 2	1845 A 5	1802 A 3
1841 C 6	9831 B 4	9820 C 4	9808 A 3	7824 B 2	5801 B 3	4890 B 4	3855 C 1	3844 B 3	3834 B 3	3824 A 3	3812 B 2	3802 A 2	2840 B 2	2830 B 3	2820 A 3	2810 A 2	2800 B 2	1803 B 5
1842 B 6	9832 B 5	9821 C 4	9810 A 3	7825 C 3	5802 B 2	4891 B 4	4850 C 3	3845 C 1	3835 C 3	3825 A 3	3813 B 2	3803 B 2	2841 B 1	2831 B 4	2821 A 4	2811 B 2	2801 B 2	1804 A 5
	9833 A 5	9822 C 4	9811 A 3	9800 C 1	7800 A 2	4892 A 3	4851 B 3	3846 C 1	3836 C 4	3826 A 4	3814 A 2	3804 A 2	2842 C 2	2832 B 4	2822 A 4	2812 B 2	2802 B 2	1806 A 5
	9834 B 5	9823 C 4	9812 A 3	9801 B 1	7801 B 3	4893 C 4	4852 C 3	3847 B 1	3837 B 4	3827 B 3	3815 C 3	3805 B 2	2843 C 2	2833 A 4	2823 A 4	2813 A 3	2803 A 2	1811 B 4
	9835 B 4	9824 C 4	9814 A 3	9802 A 1	7802 A 4	4894 B 2	4853 B 3	3849 B 2	3838 A 5	3828 A 4	3816 A 3	3806 A 2	2856 A 4	2834 C 2	2824 A 4	2814 B 2	2804 A 2	1812 A 1
	9836 B 5	9825 C 4	9815 A 4	9803 A 2	7803 B 3	4895 A 1	4854 B 3	3850 C 2	3839 C 3	3829 A 4	3817 A 3	3807 A 2	2896 C 3	2835 C 2	2825 A 3	2815 A 2	2805 B 2	1820 C 5
	9837 A 3	9827 C 4	9816 B 3	9804 A 2	7820 B 1	4896 B 2	4855 A 4	3851 C 2	3840 B 2	3830 A 3	3818 A 4	3808 A 2	2897 B 3	2836 A 2	2826 A 3	2816 A 2	2806 A 2	1821 C 2
	9838 B 2	9828 B 4	9817 B 4	9805 B 2	7821 B 2	4897 C 3	4856 A 4	3852 C 2	3841 B 2	3831 B 3	3820 B 3	3809 B 2	2898 B 3	2837 A 2	2827 C 3	2817 A 4	2807 B 2	1830 A 4
	----	9829 B 4	9818 C 3	9806 C 3	7822 C 2	4898 A 4	4857 B 4	3853 C 2	3842 B 2	3832 C 3	3821 A 4	3810 A 3	3800 A 1	2838 A 2	2828 B 3	2818 A 4	2808 A 2	1831 A 4




DECODER CIRCUIT DIAGRAM






- 1008 L1
- 1008 K1
- 1008 K1
- 1008 L1
- 1008 M1
- 1008 M1
- 1010 N26
- 1010 D1
- 1010 E1
- 1010 E1
- 1010 D1
- 1010 F1
- 1010 F1
- 1010 G1
- 1010 D1
- 1010 E26
- 1010 E1
- 1010 H1
- 1010 H1
- 1010 G1
- 1010 G1
- 1010 L1
- 1010 G1
- 1050 H19
- 1071 H26
- 1071 G26
- 1101 L12
- 1410 C26
- 1410 B26
- 1410 B26
- 1410 C26
- 1410 O3
- 1410 O3
- 1410 O4
- 1410 O4
- 1410 D26
- 1410 C26
- 1410 E26
- 1410 D26
- 1410 E26
- 1602 B25
- 2100 G8
- 2101 G10
- 2102 G11
- 2103 G9
- 2105 G13
- 2110 L15
- 2111 L14
- 2112 L13
- 2113 L12
- 2114 L12
- 2115 H9
- 2118 H8
- 2118 H1
- 2140 N18
- 2141 N20
- 2142 G10
- 2143 L13
- 2501 J4
- 2502 J5
- 2504 K4
- 2600 H25
- 2601 H25
- 2602 G25
- 2701 B20
- 2703 B21
- 2704 E26
- 2705 E25
- 2707 B26
- 3100 G9
- 3101 G9
- 3102 G2
- 3107 G12
- 3108 G13
- 3109 I15
- 3110 J15
- 3111 J15
- 3113 L15
- 3114 L12
- 3115 H8
- 3116 L12
- 3117 L13
- 3140 N16
- 3141 N16
- 3142 N17
- 3143 N18
- 3144 M19
- 3145 N20
- 3146 L10
- 3147 N18
- 3500 H17
- 3501 H18
- 3502 I18
- 3503 G18
- 3504 C11
- 3505 B11
- 3508 G2
- 3601 H24
- 3602 H23
- 3603 H25
- 3604 G23
- 3606 F24
- 3607 F23
- 3608 G26
- 3609 A15
- 3700 G19
- 3701 B24
- 3703 A17
- 3706 B22
- 3707 B23
- 3708 B23
- 3709 B24
- 3710 E25
- 3711 B17
- 3714 A18
- 3715 G12
- 3716 F8
- 3717 B8
- 3718 B9
- 3719 E14
- 3720 F14
- 3723 B23
- 3724 B22
- 3725 C21
- 3726 B9
- 3727 E14
- 3735 B9
- 3736 B7
- 3737 B8
- 3738 B9
- 3740 B16
- 3751 C14
- 3752 A19
- 3999 N26
- 4011 C25
- 4012 E25
- 5100 L12
- 5500 I17
- 7100 H14
- 7500 H18
- 7501 A11
- 7502 J4
- 7600 G24
- 7600 N19
- 7601 S15
- 7700 B21

9056 F 3	3999 B 4	3143 E 3	1008 F 1
9057 A 1	4000 B 3	3144 E 3	1010 D 4
9058 B 2	4001 A 3	3145 E 4	1020 B 1
9060 C 1	4002 A 1	3146 B 1	1050 E 2
9061 E 2	4003 B 3	3147 E 3	1071 F 3
9130 E 1	4004 C 3	3252 A 1	1073 A 1
9131 E 1	4005 A 3	3300 C 3	1101 A 1
9134 D 2	4006 B 1	3301 B 2	1250 A 1
9135 C 1	4009 C 1	3302 B 3	1300 A 2
9136 D 3	4010 E 2	3303 B 3	1301 B 2
9137 D 3	4011 E 2	3304 B 2	1302 A 4
	4012 F 2	3305 B 3	1410 F 3
	4013 F 2	3306 A 2	1602 D 1
	4014 D 1	3307 A 2	1750 A 3
	4300 A 2	3308 A 2	1751 A 3
	4301 A 2	3309 A 2	1800 D 1
	4501 F 1	3310 B 2	1815 B 4
	4740 A 4	3330 C 2	2100 A 1
	5100 A 1	3331 B 2	2101 A 1
	5250 A 1	3332 A 2	2102 A 1
	5300 B 2	3333 B 3	2103 B 1
	5301 B 3	3334 B 3	2105 B 1
	5501 E 1	3360 B 2	2110 B 1
	5502 E 1	3361 B 1	2111 B 1
	6360 B 3	3362 B 3	2112 B 1
	6361 B 2	3363 A 2	2113 A 1
	6500 D 2	3364 A 2	2114 A 1
	6740 A 4	3365 A 2	2115 A 1
	7100 B 1	3366 A 2	2116 A 1
	7300 C 2	3367 B 2	2118 B 1
	7301 B 3	3368 B 3	2140 E 3
	7302 C 2	3369 A 1	2141 E 4
	7360 B 3	3376 A 2	2142 B 1
	7361 A 1	3377 A 2	2143 B 1
	7362 A 2	3500 D 2	2251 A 1
	7363 A 2	3501 D 2	2253 A 1
	7364 A 2	3502 D 2	2254 A 1
	7365 B 2	3503 D 1	2300 B 3
	7500 D 2	3504 D 1	2301 C 3
	7501 E 1	3505 E 1	2302 B 3
	7502 C 1	3506 E 1	2303 C 3
	7600 E 3	3507 E 1	2304 B 3
	7601 C 1	3508 C 3	2305 B 3
	7700 D 1	3600 D 3	2306 A 3
	7730 D 2	3601 E 3	2307 A 3
	7740 A 3	3602 E 3	2308 A 2
	7741 A 3	3603 E 4	2309 A 2
	7742 A 4	3604 E 2	2310 B 3
	9000 A 1	3605 D 3	2311 B 3
	9001 B 2	3606 E 4	2312 B 3
	9002 B 2	3607 E 3	2313 C 2
	9003 B 2	3608 E 4	2314 B 3
	9004 B 2	3609 E 1	2315 B 2
	9005 B 1	3700 E 2	2316 C 3
	9006 C 3	3701 D 1	2317 A 2
	9007 E 1	3702 E 1	2330 B 2
	9008 A 3	3703 E 1	2331 C 2
	9009 A 3	3704 D 2	2332 C 2
	9010 A 1	3705 C 1	2333 C 2
	9011 B 3	3706 D 1	2334 C 2
	9012 B 3	3707 E 2	2335 B 2
	9013 A 2	3708 E 2	2336 B 3
	9014 A 2	3709 D 1	2337 B 3
	9015 E 1	3710 E 1	2338 A 3
	9016 E 1	3711 E 1	2339 C 2
	9017 B 1	3712 E 1	2500 C 1
	9018 C 1	3713 E 1	2501 C 1
	9019 D 1	3714 E 1	2502 C 1
	9020 E 1	3715 B 1	2503 E 1
	9021 C 3	3716 D 2	2504 E 1
	9022 C 3	3717 D 1	2505 D 3
	9023 C 3	3718 D 1	2600 E 4
	9024 E 1	3719 D 1	2601 E 4
	9025 D 1	3720 D 1	2602 E 3
	9026 E 2	3721 D 1	2700 D 2
	9027 D 2	3722 D 2	2701 D 1
	9028 E 2	3723 D 1	2703 D 2
	9029 D 4	3724 E 2	2704 F 3
	9030 D 4	3725 D 1	2705 F 2
	9031 D 3	3726 D 2	2706 F 2
	9032 D 3	3727 E 2	2707 F 3
	9033 D 3	3728 B 4	2708 E 3
	9034 D 3	3729 E 1	2709 E 3
	9035 D 2	3730 B 4	2710 E 3
	9036 E 2	3732 B 4	2730 D 2
	9037 D 3	3733 E 1	2740 A 3
	9038 D 2	3734 B 4	2741 A 3
	9039 D 2	3735 D 1	2742 A 3
	9040 E 3	3736 E 1	3100 A 1
	9041 E 4	3737 D 1	3101 A 1
	9042 C 1	3738 E 1	3102 C 3
	9043 C 1	3739 E 2	3107 B 1
	9044 C 4	3740 E 2	3108 B 1
	9045 C 1	3743 A 3	3109 B 1
	9046 C 1	3744 A 3	3110 B 1
	9047 D 2	3745 A 3	3111 B 1
	9048 D 2	3746 A 3	3113 A 1
	9049 C 2	3747 A 3	3114 A 1
	9050 D 1	3748 A 3	3115 A 1
	9051 D 1	3749 A 4	3116 B 1
	9052 D 1	3750 A 4	3117 B 1
	9053 D 1	3751 D 1	3140 E 4
	9054 C 2	3752 E 1	3141 E 4
	9055 C 1	3753 E 1	3142 E 3




- 1=TM
- 2=CAR SWITCH
- 3=LOAD SWITCH
- 4=CARMOT
- 5=QUICK PLAY
- 6=SICL
- 7=SIDA
- 8=SIDL
- 9=NRST
- 10=SLEDGE SWITCH
- 11=DISPOS
- 12=GND
- 13=GND
- 14=GND
- 15=+10V
- 16=-10V
- 17=OTD
- 18=HF

1071	TRAY MOTOR	1410	DISPLAY	1008	POWER SUPPLY
	1=TRAY MOTOR		1=IR		1=+10V
	2=GND		2=GND		2=-10V
			3=+5V		3=KILL
			4=DISRES		4=GND
			5=VAC2		5=VFTD
			6=VAC1		6=VAC1
			7=VFTD		7=VAC2
			8=SCK		
			9=SDATO		
			10=ACK		
			11=SDIS		



1008 F 1	3143 E 3	3999 B 4	9056 F 3
1010 D 4	3144 E 3	4000 B 3	9057 A 1
1020 B 1	3145 E 4	4001 A 3	9058 B 2
1050 E 2	3146 B 1	4002 A 1	9060 C 1
1071 F 3	3147 E 3	4003 B 3	9061 E 2
1073 A 1	3252 A 1	4004 C 3	9130 E 1
1101 A 1	3300 C 3	4005 A 3	9131 E 1
1250 A 1	3301 B 2	4006 B 1	9134 D 2
1300 A 2	3302 B 3	4009 C 1	9135 C 1
1301 B 2	3303 B 3	4010 E 2	9136 D 3
1302 A 4	3304 B 2	4011 E 2	9137 D 3
1410 F 3	3305 B 3	4012 F 2	
1602 D 1	3306 A 2	4013 F 2	
1750 A 3	3307 A 2	4014 D 1	
1751 A 3	3308 A 2	4300 A 2	
1800 D 1	3309 A 2	4301 A 2	
1815 B 4	3310 B 2	4501 F 1	
2100 A 1	3330 C 2	4740 A 4	
2101 A 1	3331 B 2	5100 A 1	
2102 A 1	3332 A 2	5250 A 1	
2103 B 1	3333 B 3	5300 B 2	
2105 B 1	3334 B 3	5301 B 3	
2110 B 1	3360 B 2	5501 E 1	
2111 B 1	3361 B 1	5502 E 1	
2112 B 1	3362 B 3	6360 B 3	
2113 A 1	3363 A 2	6361 B 2	
2114 A 1	3364 A 2	6500 D 2	
2115 A 1	3365 A 2	6740 A 4	
2116 A 1	3366 A 2	7100 B 1	
2118 B 1	3367 B 2	7300 C 2	
2140 E 3	3368 B 3	7301 B 3	
2141 E 4	3369 A 1	7302 C 2	
2142 B 1	3376 A 2	7360 B 3	
2143 B 1	3377 A 2	7361 A 1	
2251 A 1	3500 D 2	7362 A 2	
2253 A 1	3501 D 2	7363 A 2	
2254 A 1	3502 D 2	7364 A 2	
2300 B 3	3503 D 1	7365 B 2	
2301 C 3	3504 D 1	7500 D 2	
2302 B 3	3505 E 1	7501 E 1	
2303 C 3	3506 E 1	7502 C 1	
2304 B 3	3507 E 1	7600 E 3	
2305 B 3	3508 C 3	7601 C 1	
2306 A 3	3600 D 3	7700 D 1	
2307 A 3	3601 E 3	7730 D 2	
2308 A 2	3602 E 3	7740 A 3	
2309 A 2	3603 E 4	7741 A 3	
2310 B 3	3604 E 2	7742 A 4	
2311 B 3	3605 D 3	9000 A 1	
2312 B 3	3606 E 4	9001 B 2	
2313 C 2	3607 E 3	9002 B 2	
2314 B 3	3608 E 4	9003 B 2	
2315 B 2	3609 E 1	9004 B 2	
2316 C 3	3700 E 2	9005 B 1	
2317 A 2	3701 D 1	9006 C 3	
2330 B 2	3702 E 1	9007 E 1	
2331 C 2	3703 E 1	9008 A 3	
2332 C 2	3704 D 2	9009 A 3	
2333 C 2	3705 C 1	9010 A 1	
2334 C 2	3706 D 1	9011 B 3	
2335 B 2	3707 E 2	9012 B 3	
2336 B 3	3708 E 2	9013 A 2	
2337 B 3	3709 D 1	9014 A 2	
2338 A 3	3710 E 1	9015 E 1	
2339 C 2	3711 E 1	9016 E 1	
2500 C 1	3712 E 1	9017 B 1	
2501 C 1	3713 E 1	9018 C 1	
2502 C 1	3714 E 1	9019 D 1	
2503 E 1	3715 B 1	9020 E 1	
2504 E 1	3716 D 2	9021 C 3	
2505 D 3	3717 D 1	9022 C 3	
2600 E 4	3718 D 1	9023 C 3	
2601 E 4	3719 D 1	9024 E 1	
2602 E 3	3720 D 1	9025 D 1	
2700 D 2	3721 D 1	9026 E 2	
2701 D 1	3722 D 2	9027 D 2	
2703 D 2	3723 D 1	9028 E 2	
2704 F 3	3724 E 2	9029 D 4	
2705 F 2	3725 D 1	9030 D 4	
2706 F 2	3726 D 2	9031 D 3	
2707 F 3	3727 E 2	9032 D 3	
2708 E 3	3728 B 4	9033 D 3	
2709 E 3	3729 E 1	9034 D 3	
2710 E 3	3730 B 4	9035 D 2	
2730 D 2	3732 B 4	9036 E 2	
2740 A 3	3733 E 1	9037 D 3	
2741 A 3	3734 B 4	9038 D 2	
2742 A 3	3735 D 1	9039 D 2	
3100 A 1	3736 E 1	9040 E 3	
3101 A 1	3737 D 1	9041 E 4	
3102 C 3	3738 E 1	9042 C 1	
3107 B 1	3739 E 2	9043 C 1	
3108 B 1	3740 E 2	9044 C 4	
3109 B 1	3743 A 3	9045 C 1	
3110 B 1	3744 A 3	9046 C 1	
3111 B 1	3745 A 3	9047 D 2	
3113 A 1	3746 A 3	9048 D 2	
3114 A 1	3747 A 3	9049 C 2	
3115 A 1	3748 A 3	9050 D 1	
3116 B 1	3749 A 4	9051 D 1	
3117 B 1	3750 A 4	9052 D 1	
3140 E 4	3751 D 1	9053 D 1	
3141 E 4	3752 E 1	9054 C 2	
3142 E 3	3753 E 1	9055 C 1	

DAC CIRCUIT DIAGRAM




- 1250 M16
- 1300 H16
- 1301 E17
- 1301 K17
- 1301 E16
- 1301 F17
- 1750 B17
- 2253 M15
- 2254 M16
- 2301 K7
- 2302 H9
- 2303 J9
- 2304 G12
- 2305 K12
- 2306 H13
- 2307 J13
- 2308 H15
- 2309 K15
- 2313 I9
- 2314 G8
- 2317 J2
- 2330 G4
- 2331 G4
- 2332 G5
- 2333 G6
- 2334 G6
- 2335 G6
- 2336 I12
- 2337 I11
- 2338 I12
- 2339 I11
- 2740 B15
- 2741 D12
- 2742 D16
- 3252 M15
- 3302 G10
- 3303 J10
- 3304 G12
- 3305 K12
- 3306 H13
- 3307 K13
- 3308 H14
- 3309 J14
- 3310 K2
- 3330 F4
- 3331 F5
- 3332 F6
- 3333 H11
- 3334 I11
- 3360 F9
- 3361 K9
- 3362 G11
- 3363 L11
- 3364 H14
- 3365 K14
- 3366 F14
- 3367 L14
- 3368 E10
- 3369 K10
- 3375 F14
- 3377 K14
- 3743 D13
- 3744 A15
- 3745 C13
- 3746 B13
- 3747 B14
- 3748 B12
- 3749 B11
- 3750 B13
- 4000 I10
- 5250 M15
- 6360 F11
- 6361 K11
- 6740 B14
- 7300 G7
- 7301 J12
- 7301 H12
- 7360 F10
- 7361 K10
- 7362 H15
- 7363 K15
- 7364 F15
- 7365 L15
- 7740 B14
- 7741 B12
- 7742 B12

CONTROL & DISPLAY CIRCUIT DIAGRAM
I.R. CIRCUIT DIAGRAM

24


24




- 1400 E17
- 1401 E3
- 1402 G1
- 1403 G1
- 1404 M8
- 1405 M8
- 1406 M8
- 1407 M8
- 1408 M8
- 1409 M8
- 1410 M8
- 1411 M8
- 1412 M8
- 1413 M8
- 1414 M8
- 1415 M8
- 1416 M8
- 1417 M8
- 1418 M8
- 1419 M8
- 1420 M8
- 1421 M8
- 1422 M8
- 1423 M8
- 1424 M8
- 1425 M8
- 1426 M8
- 1427 M8
- 1428 M8
- 1429 M8
- 1430 M8
- 1431 M8
- 1432 M8
- 1433 M8
- 1434 M8
- 1435 M8
- 1436 M8
- 1437 M8
- 1438 M8
- 1439 M8
- 1440 M8
- 1441 M8
- 1442 M8
- 1443 M8
- 1444 M8
- 1445 M8
- 1446 M8
- 1447 M8
- 1448 M8
- 1449 M8
- 1450 M8
- 1451 M8
- 1452 M8
- 1453 M8
- 1454 M8
- 1455 M8
- 1456 M8
- 1457 M8
- 1458 M8
- 1459 M8
- 1460 M8
- 1461 M8
- 1462 M8
- 1463 M8
- 1464 M8
- 1465 M8
- 1466 M8
- 1467 M8
- 1468 M8
- 1469 M8
- 1470 M8
- 1471 M8
- 1472 M8
- 1473 M8
- 1474 M8
- 1475 M8
- 1476 M8
- 1477 M8
- 1478 M8
- 1479 M8
- 1480 M8
- 1481 M8
- 1482 M8
- 1483 M8
- 1484 M8
- 1485 M8
- 1486 M8
- 1487 M8
- 1488 M8
- 1489 M8
- 1490 M8
- 1491 M8
- 1492 M8
- 1493 M8
- 1494 M8
- 1495 M8
- 1496 M8
- 1497 M8
- 1498 M8
- 1499 M8
- 1500 M8


3104 113 301315-A
9248

CONTROL & DISPLAY PANEL
OPEN/CLOSE - I.R. PANEL







HEADPHONE CIRCUIT DIAGRAM




HEADPHONE PANEL



START UP PROCEDURE





SERVICE TEST PROGRAM



HAS1137
9419

FAULTFINDING GUIDE






HAS1137
9419

HAS1140
9419

SPECIFICATIONS MEASUREMENT

SIGNAL	AUDIO SIGNALS DISC 1	TESTPOINT	REMARKS
ANALOG OUT LEFT	TOTAL HARMONIC DISTORTION TRACKS 10 - 23	FILTER OUTPUT	SEE TECHNICAL DATA
ANALOG OUT RIGHT			SEE DRAWING
ANALOG OUT LEFT	SIGNAL-TO-NOISE RATIO TRACK 1 REFERENCE LEVEL TRACK 49	FILTER OUTPUT	SEE TECHNICAL DATA
ANALOG OUT RIGHT			SEE DRAWING

FILTER = 13TH ORDER FILTER 4822 395 30204




PARTS LIST LOADING

89	4822 466 93131	PRESSURE PLATE
90	4822 256 91912	PRESSURE RING HOLDER
91	4822 532 52386	PRESSURE RING
95	4822 522 33255	GEAR WHEEL
96	4822 535 40105	CRANCK
98	4822 691 30278	CDM 12.1 MECHANISM
99	4822 403 70598	CDM LOCKING BRACKET
100	4822 466 93129	ROTARY DISC 5 CD'S
101	4822 520 20758	BEARING
103	4822 401 11447	TRAY TUMBLER
104	4822 325 50215	SUSPENSION
105	4822 325 50215	SUSPENSION
106	4822 325 50215	SUSPENSION
107	4822 325 50215	SUSPENSION
108	4822 444 50685	TRAY ASSY
109	4822 532 51756	DAMPING GROMMET
110	4822 401 11444	BRACKET
113	4822 492 52313	TENSION SPRING
114	4822 256 91915	CDM SUPPORT
115	4822 466 93134	SLIDE STRIP
116	4822 522 33256	CAM WHEEL
119	4822 528 50335	MOTOR
120	4822 528 50335	MOTOR
121	4822 528 50334	PULLEY
122	4822 358 10115	BELT
128	4822 466 93132	GUIDE
129	4822 466 93132	GUIDE
130	4822 426 90109	FRAME ASSY
131	4822 466 93132	GUIDE
132	4822 403 70599	KEY UNIT
133	4822 466 93171	COVER PLATE
136	4822 528 70646	ROLLER
137	4822 528 70646	ROLLER
138	4822 528 70646	ROLLER
139	4822 528 70646	ROLLER
140	4822 528 70646	ROLLER
141	4822 466 93132	GUIDE
142	4822 466 93132	GUIDE
144	4822 528 50334	PULLEY
145	4822 358 10115	DRIVING BELT
146	4822 402 50291	LIFT TUMBLER
147	4822 402 50291	LIFT TUMBLER
148	4822 492 52123	COMPRESSION SPRING
149	4822 492 52123	COMPRESSION SPRING
150	4822 492 52123	COMPRESSION SPRING



Screws

Plastite M3x6:	125
Plastite M3x10:	111,112
Plastite M3x10 + wascher:	97,126
Plastite M3x16:	102,134

EXPLODED VIEW LOADING



EXPLODED VIEW
LOADING



M: TO LUBRICATE WITH: 4822 390 20128 GREASE

MECHANICAL PARTS LIST CABINET


2	4822 444 40792	FRONT(CC45)
2	4822 444 40758	FRONT(CC65)
14	4822 454 12948	WORDMARK
15	4822 410 63355	KNOBUNIT(NOSE)
16	4822 410 63354	KNOBUNIT
17	4822 410 63356	KNOBUNIT(10-KEY CC65)
22	4822 450 62296	WINDOW(CC45)
22	4822 450 62295	WINDOW(CC65)
23	4822 450 62294	IR WINDOW
51	4822 410 61467	VOLUME KNOB(CC65)
54	4822 466 93132	GUIDE
60	4822 444 60815	COVER PLATE
71	4822 444 50729	TRAY FRONT
151	4822 444 60995	COVER
180	4822 462 72053	CAP
182	4822 402 61544	POWERROD
251	4822 462 42129	FOOT GOLD FRONT
252	4822 462 42129	FOOT GOLD FRONT
253	4822 462 42131	FOOT GOLD REAR
254	4822 462 42131	FOOT GOLD REAR
283 ▲	4822 532 60948	BUSHING
300 ▲	4822 321 10809	MAINS CORD /02B
302 ▲	4822 321 10849	MAINS CORD /UBL
303 ▲	4822 321 10828	MAINS CORD /07B
308	4822 321 22832	SBC1072 AUDIO CABLE
365	4822 218 10556	REMOTE CONTROL RH7920(CC45)
365	4822 218 10553	REMOTE CONTROL(CC65)

Not mentioned parts are only available during production period on special request.


Screws

Selftapping screw for plastic 3x10: 78,79,202,203,204,205,206,269,270,271,272.
 Selftapping screw for plastic 3x12: 30,31,32,33,34,35,36,37,38,39,40,41,42,43,44,45.
 Selftapping screw for metal M3x6 : 75,76,77,259,260,261,262.
 Selftapping screw for metal with washer 3x6: 173,174,175,176,177,178,200,201,211,267,268.
 Selftapping screw for metal M3x28: 207,208,209,210.

EXPLODED VIEW CABINET



EXPLODED VIEW CABINET



it.
268.

ELECTRICAL PARTS LIST

POWER SUPPLY PANEL			SERVO PANEL		
MISCELLANEOUS			MISCELLANEOUS		
1500 ▲	4822 276 13277	MAINS SWITCH	4822 323 50157	FLEXFOIL 18P	
1501 ▲	4822 252 51167	FUSE T 200mA/(UBL)	1802	4822 242 73557	RESONATOR 8.46MHz
1501 ▲	4822 071 51001	FUSE T 100mA (CC65/02B/07B)	1820	4822 276 13106	TACT SWITCH
1501 ▲	4822 252 51168	FUSE T 80mA (CC45/02B/07B)	1821	4822 276 13106	TACT SWITCH
CAPACITORS			CAPACITORS		
2500	4822 126 11585	22nF +80-20% 25V	2800	4822 126 10326	180pF 5% 63V
2501	4822 126 11585	22nF +80-20% 25V	2801	4822 126 10326	180pF 5% 63V
2502	4822 126 11585	22nF +80-20% 25V	2802	5322 122 31863	330pF 5% 50V
2503	4822 126 11585	22nF +80-20% 25V	2803	5322 122 31865	1,5nF 10% 63V
2504	4822 126 11585	22nF +80-20% 25V	2804	5322 116 80853	560pF 5% 63V
2505	4822 126 11585	22nF +80-20% 25V	2805	4822 122 33575	220pF 5%NPO 50V
2506	4822 124 80951	3300µF 20% 16V(CC65)	2806	4822 122 33575	220pF 5%NPO 50V
2506	4822 124 40784	3300µF 20% 16V(CC45)	2807	4822 122 33575	220pF 5%NPO 50V
2507	4822 126 12882	100nF +80-20% 50V	2808	4822 122 33575	220pF 5%NPO 50V
2508	5322 124 22094	220µF 20% 50V	2809	4822 122 33575	220pF 5%NPO 50V
2509	4822 124 41596	22µF 20% 50V	2810	4822 122 33575	220pF 5%NPO 50V
2510	4822 124 80949	2200µF 20% 16V(CC65)	2811	4822 122 33496	100nF 10% 63V
2510	4822 124 80253	2200µF 20% 25V(CC45)	2812	5322 124 21643	22µF 20% 40V
2544	4822 126 10454	3,3nF 20% 400V	2813	5322 122 32654	22nF 10% 63V
2560	4822 124 40849	330µF 20% 16V	2814	4822 122 33496	100nF 10% 63V
RESISTORS			RESISTORS		
3560	4822 050 11002	1k 1% 0,4W	2815	4822 122 33496	100nF 10% 63V
DIODES & IC			DIODES & IC		
6500	5322 130 30684	1N4002GP	2817	4822 126 10326	180pF 5% 63V
6501	5322 130 30684	1N4002GP	2818	4822 122 33496	100nF 10% 63V
6502	5322 130 30684	1N4002GP	2819	5322 124 41431	22µF 20% 35V
6503	5322 130 30684	1N4002GP	2820	5322 126 10465	3,9nF 10% 63V
6504	5322 130 30684	1N4002GP	2821	4822 122 33496	100nF 10% 63V
6505	4822 130 31981	BZX79-C3V9	2822	5322 124 41431	22µF 20% 35V
6506	5322 130 32586	BZV85-C7V5	2823	4822 122 33496	100nF 10% 63V
6507	5322 130 30684	1N4002GP	2824	4822 126 10326	180pF 5% 63V
6508	5322 130 30684	1N4002GP	2825	4822 122 32627	2,7nF 10% 50V
6560	5322 130 30684	1N4002GP	2826	4822 122 33496	100nF 10% 63V
6561	5322 130 30684	1N4002GP	2827	4822 122 33175	2,2nF 20% 50V
6562	4822 130 31981	BZX79-C3V9	2828	4822 122 33496	100nF 10% 63V
7500	4822 209 31257	MC79L24ACP	2829	5322 124 41431	22µF 20% 35V
			2830	4822 122 33342	33nF 10% 63V
			2831	4822 122 33496	100nF 10% 63V
			2832	5322 124 41431	22µF 20% 35V
			2833	4822 122 33496	100nF 10% 63V
			2834	5322 124 41431	22µF 20% 35V
			2835	4822 122 33496	100nF 10% 63V
			2836	5322 122 32452	47pF 5% 63V
			2837	5322 122 32452	47pF 5% 63V
			2838	5322 122 32531	100pF 5% 50V
			2839	5322 122 32965	18pF 5%NPO 50V
			2840	4822 126 10326	180pF 5% 63V
			2841	5322 124 21643	22µF 20% 40V
			2842	5322 122 31863	330pF 5% 50V
			2843	4822 126 10326	180pF 5% 63V
			2856	4822 122 33496	100nF 10% 63V
			2896	5322 124 41431	22µF 20% 35V
			2897	4822 124 40433	47µF 20% 25V
			2898	4822 124 40433	47µF 20% 25V

RESISTORS		
3800	4822 116 52239	120k 5% 0,5W
3801	4822 116 52233	10k 5% 0,5W
3802	4822 116 52239	120k 5% 0,5W
3803	4822 116 52233	10k 5% 0,5W
3804	4822 116 52291	56k 5% 0,5W
3805	4822 116 52233	10k 5% 0,5W
3806	4822 116 52233	10k 5% 0,5W
3807	4822 116 52233	10k 5% 0,5W
3808	4822 116 52233	10k 5% 0,5W
3809 ▲	4822 052 10478	4Ω 5% 0,33W
3810 ▲	4822 052 10478	4Ω 5% 0,33W
3811	4822 051 20105	1M 5% 0,1W
3812	4822 050 11002	1k 1% 0,4W
3813	4822 050 11002	1k 1% 0,4W
3814	4822 116 52233	10k 5% 0,5W
3815	4822 116 52175	100Ω 5% 0,5W
3816	4822 051 20103	10k 5% 0,1W
3817	4822 116 52244	15k 5% 0,5W
3818	4822 116 52244	15k 5% 0,5W
3820	4822 051 20682	6k8 5% 0,1W
3821	4822 116 52283	4k7 5% 0,5W
3822	4822 116 52233	10k 5% 0,5W
3824 ▲	4822 052 10229	22Ω 5% 0,33W
3825	4822 116 52244	15k 5% 0,5W
3826	4822 116 52244	15k 5% 0,5W
3827	4822 051 20103	10k 5% 0,1W
3828	4822 116 52296	6k8 5% 0,5W
3829	4822 116 52233	10k 5% 0,5W
3830 ▲	4822 052 10229	22Ω 5% 0,33W
3831	4822 051 20153	15k 5% 0,1W
3832	4822 116 52244	15k 5% 0,5W
3833 ▲	4822 052 10478	4Ω 5% 0,33W
3834	4822 117 10362	7k5 1% 0,1W
3835	4822 116 52296	6k8 5% 0,5W
3836	4822 116 52233	10k 5% 0,5W
3837 ▲	4822 052 10478	4Ω 5% 0,33W
3838 ▲	4822 052 10229	22Ω 5% 0,33W
3839	4822 116 52175	100Ω 5% 0,5W
3840	4822 116 52277	39k 5% 0,5W
3841	4822 050 11002	1k 1% 0,4W
3842	4822 116 52175	100Ω 5% 0,5W
3843	4822 116 52249	1k8 5% 0,5W
3844	4822 116 52175	100Ω 5% 0,5W
3845	4822 051 20431	430Ω 5% 0,1W
3846	4822 051 20431	430Ω 5% 0,1W
3847	4822 051 20334	330k 5% 0,1W
3849	4822 051 20303	30k 5% 0,1W
3850	4822 050 11002	1k 1% 0,4W
3851	4822 051 20362	3k6 5% 0,1W
3852	4822 116 52175	100Ω 5% 0,5W
3853	4822 116 52249	1k8 5% 0,5W
3854	4822 050 11002	1k 1% 0,4W
3855	4822 051 20431	430Ω 5% 0,1W
4850	4822 116 52231	820Ω 5% 0,5W
4851	4822 116 52238	12k 5% 0,5W
4852	4822 051 20123	12k 5% 0,1W
4853	4822 116 52238	12k 5% 0,5W
4854	4822 116 52238	12k 5% 0,5W
4855 ▲	4822 052 10229	22Ω 5% 0,33W
4856 ▲	4822 052 10108	1Ω 5% 0,33W
4857	4822 116 52284	47k 5% 0,5W

4858	4822 116 52284	47k 5% 0,5W
4890	4822 051 20271	270Ω 5% 0,1W
4892	4822 116 52217	270Ω 5% 0,5W
4893	4822 116 52217	270Ω 5% 0,5W
4894	4822 051 10008	0Ω 5% 0,25W
4895	4822 051 10008	0Ω 5% 0,25W
4896	4822 051 10008	0Ω 5% 0,25W
4897	4822 051 10008	0Ω 5% 0,25W
4898	4822 051 10008	0Ω 5% 0,25W
4899	4822 051 10008	0Ω 5% 0,25W
COILS		
5801	4822 157 53447	COIL
5802	4822 157 53447	COIL
TRANSISTORS & IC'S		
7800	4822 209 31064	TDA1301T/N1
7801	4822 209 71579	MC7805.2
7802	4822 209 72587	TCA0372
7803	4822 209 72587	TCA0372
7820	4822 130 60887	BF840
7821	5322 130 41982	BC848B
7822	5322 130 41983	BC858B
7823	5322 130 41982	BC848B
7824	5322 130 41982	BC848B
7825	4822 130 42675	BC818

26	4
1010	4
1050	5
1101	4
1250	4
1300	4
1602	4
1750	4
2100	4
2101	5
2102	5
2103	4
2105	5
2110	4
2111	5
2112	4
2113	4
2114	5
2115	5
2116	4
2118	5
2140	4
2141	4
2142	5
2143	5
2251	4
2253	4
2254	5
2301	5
2302	4
2302	4
2303	4
2303	4
2304	5
2305	5
2306	4
2306	4
2307	4
2307	4
2308	4
2309	4
2313	4
2314	4
2317	4
2330	4
2331	4
2332	4
2333	4
2334	4
2335	4
2336	4
2337	4
2338	4
2339	4
2501	4

RESISTORS

3800	4822 116 52239	120k 5% 0,5W
3801	4822 116 52233	10k 5% 0,5W
3802	4822 116 52239	120k 5% 0,5W
3803	4822 116 52233	10k 5% 0,5W
3804	4822 116 52291	56k 5% 0,5W
3805	4822 116 52233	10k 5% 0,5W
3806	4822 116 52233	10k 5% 0,5W
3807	4822 116 52233	10k 5% 0,5W
3808	4822 116 52233	10k 5% 0,5W
3809 ▲	4822 052 10478	4Ω7 5% 0,33W
3810 ▲	4822 052 10478	4Ω7 5% 0,33W
3811	4822 051 20105	1M 5% 0,1W
3812	4822 050 11002	1k 1% 0,4W
3813	4822 050 11002	1k 1% 0,4W
3814	4822 116 52233	10k 5% 0,5W
3815	4822 116 52175	100Ω 5% 0,5W
3816	4822 051 20103	10k 5% 0,1W
3817	4822 116 52244	15k 5% 0,5W
3818	4822 116 52244	15k 5% 0,5W
3820	4822 051 20682	6k8 5% 0,1W
3821	4822 116 52283	4k7 5% 0,5W
3822	4822 116 52233	10k 5% 0,5W
3824 ▲	4822 052 10229	22Ω 5% 0,33W
3825	4822 116 52244	15k 5% 0,5W
3826	4822 116 52244	15k 5% 0,5W
3827	4822 051 20103	10k 5% 0,1W
3828	4822 116 52296	6k8 5% 0,5W
3829	4822 116 52233	10k 5% 0,5W
3830 ▲	4822 052 10229	22Ω 5% 0,33W
3831	4822 051 20153	15k 5% 0,1W
3832	4822 116 52244	15k 5% 0,5W
3833 ▲	4822 052 10478	4Ω7 5% 0,33W
3834	4822 117 10362	7k5 1% 0,1W
3835	4822 116 52296	6k8 5% 0,5W
3836	4822 116 52233	10k 5% 0,5W
3837 ▲	4822 052 10478	4Ω7 5% 0,33W
3838 ▲	4822 052 10229	22Ω 5% 0,33W
3839	4822 116 52175	100Ω 5% 0,5W
3840	4822 116 52277	39k 5% 0,5W
3841	4822 050 11002	1k 1% 0,4W
3842	4822 116 52175	100Ω 5% 0,5W
3843	4822 116 52249	1k8 5% 0,5W
3844	4822 116 52175	100Ω 5% 0,5W
3845	4822 051 20431	430Ω 5% 0,1W
3846	4822 051 20431	430Ω 5% 0,1W
3847	4822 051 20334	330k 5% 0,1W
3849	4822 051 20303	30k 5% 0,1W
3850	4822 050 11002	1k 1% 0,4W
3851	4822 051 20362	3k6 5% 0,1W
3852	4822 116 52175	100Ω 5% 0,5W
3853	4822 116 52249	1k8 5% 0,5W
3854	4822 050 11002	1k 1% 0,4W
3855	4822 051 20431	430Ω 5% 0,1W
4850	4822 116 52231	820Ω 5% 0,5W
4851	4822 116 52238	12k 5% 0,5W
4852	4822 051 20123	12k 5% 0,1W
4853	4822 116 52238	12k 5% 0,5W
4854	4822 116 52238	12k 5% 0,5W
4855 ▲	4822 052 10229	22Ω 5% 0,33W
4856 ▲	4822 052 10108	1Ω 5% 0,33W
4857	4822 116 52284	47k 5% 0,5W

4858	4822 116 52284	47k 5% 0,5W
4890	4822 051 20271	270Ω 5% 0,1W
4892	4822 116 52217	270Ω 5% 0,5W
4893	4822 116 52217	270Ω 5% 0,5W
4894	4822 051 10008	0Ω 5% 0,25W
4895	4822 051 10008	0Ω 5% 0,25W
4896	4822 051 10008	0Ω 5% 0,25W
4897	4822 051 10008	0Ω 5% 0,25W
4898	4822 051 10008	0Ω 5% 0,25W
4899	4822 051 10008	0Ω 5% 0,25W

COILS

5801	4822 157 53447	COIL
5802	4822 157 53447	COIL

TRANSISTORS & IC'S

7800	4822 209 31064	TDA1301T/N1
7801	4822 209 71579	MC7805.2
7802	4822 209 72587	TCA0372
7803	4822 209 72587	TCA0372
7820	4822 130 60887	BF840
7821	5322 130 41982	BC848B
7822	5322 130 41983	BC858B
7823	5322 130 41982	BC848B
7824	5322 130 41982	BC848B
7825	4822 130 42675	BC818

DECODER-DAC PANEL

MISCELLANEOUS

26	4822 255 40991	LED SOCKET
1010	4822 267 51094	FLEX CONNECTOR
1050	5322 242 73686	RESONATOR 12 MHz
1101	4822 242 81705	CRYSTAL33.86 MHz
1250	4822 267 31729	DIGITAL OUT SOCKET
1300	4822 267 41064	ANALOG OUT SOCKET
1602	4822 276 13106	TACT SWITCH
1750	4822 267 31817	RC5 SOCKET

CAPACITORS

2100	4822 122 33175	2,2nF 20% 50V
2101	5322 122 32452	47pF 5% 63V
2102	5322 122 32654	22nF 10% 63V
2103	4822 122 33496	100nF 10% 63V
2105	5322 122 32531	100pF 5% 50V
2110	4822 124 40433	47μF 20% 25V
2111	5322 122 32654	22nF 10% 63V
2112	4822 122 33847	10pF 5% 50V
2113	4822 122 33191	22pF 5% 50V
2114	5322 122 34123	1nF 10% 50V
2115	5322 122 32654	22nF 10% 63V
2116	4822 124 40433	47μF 20% 25V
2118	5322 122 32452	47pF 5% 63V
2140	4822 122 32542	47nF 10% 63V
2141	4822 122 33496	100nF 10% 63V
2142	5322 122 32452	47pF 5% 63V
2143	5322 122 32654	22nF 10% 63V
2251	4822 124 40248	10μF 20% 63V
2253	4822 122 33496	100nF 10% 63V
2254	5322 122 32654	22nF 10% 63V
2301	5322 122 32268	470pF 10% 50V
2302	4822 124 40433	47μF 20% 25V(CC45)
2302	4822 124 80953	10μF 50V(CC65)
2303	4822 124 40433	47μF 20% 25V(CC45)
2303	4822 124 80953	10μF 50V(CC65)
2304	5322 122 32661	56pF 5% 50V
2305	5322 122 32661	56pF 5% 50V
2306	4822 124 80865	10μF 20% 25V(CC45)
2306	4822 124 80954	47μF 6,3V(CC65)
2307	4822 124 80865	10μF 20% 25V(CC45)
2307	4822 124 80954	47μF 6,3V(CC65)
2308	4822 122 33575	220pF 5%NPO 50V
2309	4822 122 33575	220pF 5%NPO 50V
2313	4822 124 40433	47μF 20% 25V
2314	5322 122 32268	470pF 10% 63V
2317	5322 122 32654	22nF 10% 63V
2330	4822 122 33496	100nF 10% 63V
2331	4822 124 40433	47μF 20% 25V
2332	4822 122 33496	100nF 10% 63V
2333	4822 124 40433	47μF 20% 25V
2334	4822 122 33496	100nF 10% 63V
2335	4822 124 40433	47μF 20% 25V
2336	4822 122 33496	100nF 10% 63V
2337	4822 124 80952	47μF 25V(ONLY CC65)
2338	4822 126 11585	22nF +80-20% 25V
2339	4822 126 11585	22nF +80-20% 25V
2501	4822 122 33496	100nF 10% 63V

2502	4822 122 33496	100nF 10% 63V
2504	4822 122 33496	100nF 10% 63V
2600	4822 122 33496	100nF 10% 63V
2601	5322 122 32654	22nF 10% 63V
2602	5322 122 32654	22nF 10% 63V
2701	5322 122 32654	22nF 10% 63V
2703	5322 122 32654	22nF 10% 63V
2704	5322 122 32531	100pF 5% 50V
2705	5322 122 32531	100pF 5% 50V
2706	5322 122 32531	100pF 5% 50V
2707	5322 122 32654	22nF 10% 63V
2740	4822 124 40433	47μF 20% 25V
2741	5322 122 32654	22nF 10% 63V
2742	5322 122 32654	22nF 10% 63V

RESISTORS

3100	4822 051 20222	2k2 5% 0,1W
3101	4822 051 20223	22k 5% 0,1W
3102	4822 116 52175	100Ω 5% 0,5W
3107	4822 051 20331	330Ω 5% 0,1W
3108	4822 051 20221	220Ω 5% 0,1W
3109	4822 051 20221	220Ω 5% 0,1W
3110	4822 051 20221	220Ω 5% 0,1W
3111	4822 051 20221	220Ω 5% 0,1W
3113 ▲	4822 052 10338	3Ω3 5% 0,33W
3114	4822 051 20105	1M 5% 0,1W
3115 ▲	4822 052 10338	3Ω3 5% 0,33W
3116	4822 051 20101	100Ω 5% 0,1W
3117	4822 051 20008	0Ω JUMP. (0805)
3140	4822 051 20333	33k 5% 0,1W
3141	4822 051 20333	33k 5% 0,1W
3142	4822 051 20333	33k 5% 0,1W
3143	4822 116 52234	100k 5% 0,5W
3144	4822 116 52234	100k 5% 0,5W
3145 ▲	4822 052 10229	22Ω 5% 0,33W
3146	4822 051 20101	100Ω 5% 0,1W
3147	4822 116 52283	4k7 5% 0,5W
3252	4822 051 20689	68Ω 5% 0,1W
3302	4822 051 20103	10k 5% 0,1W
3303	4822 051 20103	10k 5% 0,1W
3304	4822 051 20153	15k 5% 0,1W
3305	4822 051 20153	15k 5% 0,1W
3306	4822 051 20223	22k 5% 0,1W
3307	4822 051 20223	22k 5% 0,1W
3308	4822 051 10102	1k 2% 0,25W
3309	4822 051 10102	1k 2% 0,25W
3310	4822 051 20008	0Ω JUMP. (0805)
3330 ▲	4822 052 10338	3Ω3 5% 0,33W
3331 ▲	4822 052 10338	3Ω3 5% 0,33W
3332 ▲	4822 052 10338	3Ω3 5% 0,33W
3333 ▲	4822 052 10478	4Ω7 5% 0,33W
3334 ▲	4822 052 10478	4Ω7 5% 0,33W
3360	4822 116 52284	47k 5% 0,5W
3361	4822 116 52284	47k 5% 0,5W
3362	4822 116 52258	220k 5% 0,5W
3363	4822 051 20224	220k 5% 0,1W
3364	4822 051 20222	2k2 5% 0,1W
3365	4822 051 20222	2k2 5% 0,1W
3366	4822 116 52256	2k2 5% 0,5W
3367	4822 116 52256	2k2 5% 0,5W
3368	4822 051 20103	10k 5% 0,1W
3369	4822 051 20103	10k 5% 0,1W
3376	4822 051 10102	1k 2% 0,25W

3377	4822 051 10102	1k 2% 0,25W
3500	4822 051 20561	560Ω 5% 0,1W
3501	4822 051 10102	1k 2% 0,25W
3502	4822 051 20223	22k 5% 0,1W
3503	4822 051 20223	22k 5% 0,1W
3504	4822 051 20223	22k 5% 0,1W
3505	4822 051 20472	4k7 5% 0,1W
3508 ▲	4822 052 10108	1Ω 5% 0,33W
3601	4822 051 20123	12k 5% 0,1W
3602	4822 051 20123	12k 5% 0,1W
3603 ▲	4822 052 10229	22Ω 5% 0,33W
3604	4822 116 52276	3k9 5% 0,5W
3606	4822 116 52238	12k 5% 0,5W
3607	4822 051 20123	12k 5% 0,1W
3608 ▲	4822 052 10108	1Ω 5% 0,33W
3609	4822 051 20224	220k 5% 0,1W
3700	4822 051 20224	220k 5% 0,1W
3701	4822 116 52257	22k 5% 0,5W
3703	4822 051 20223	22k 5% 0,1W
3706	4822 116 52257	22k 5% 0,5W
3707	4822 116 52257	22k 5% 0,5W
3708	4822 051 20223	22k 5% 0,1W
3709	4822 051 20223	22k 5% 0,1W
3710	4822 051 20223	22k 5% 0,1W
3711	4822 051 20223	22k 5% 0,1W
3714	4822 051 20223	22k 5% 0,1W
3715	4822 051 20103	10k 5% 0,1W
3716	4822 051 20472	4k7 5% 0,1W
3717	4822 051 20223	22k 5% 0,1W
3718	4822 051 20223	22k 5% 0,1W
3719	4822 050 11002	1k 1% 0,4W
3720	4822 050 11002	1k 1% 0,4W
3723	4822 051 20223	22k 5% 0,1W
3724	4822 116 52257	22k 5% 0,5W
3725	4822 050 11002	1k 1% 0,4W
3726	4822 116 52257	22k 5% 0,5W
3727	4822 051 20562	5k6 5% 0,1W
3735	4822 051 20223	22k 5% 0,1W
3736	4822 051 20223	22k 5% 0,1W
3737	4822 051 20223	22k 5% 0,1W
3738	4822 051 20223	22k 5% 0,1W
3740	4822 051 20223	22k 5% 0,1W
3743 ▲	4822 052 10109	10Ω 5% 0,33W
3744	4822 116 52175	100Ω 5% 0,5W
3745	4822 051 20473	47k 5% 0,1W
3746	4822 051 20183	18k 5% 0,1W
3747	4822 051 20473	47k 5% 0,1W
3748	4822 051 20473	47k 5% 0,1W
3749	4822 116 52284	47k 5% 0,5W
3750	4822 051 20473	47k 5% 0,1W
3751	4822 051 10102	1k 2% 0,25W
3752	4822 051 20223	22k 5% 0,1W
4000	4822 051 10008	0Ω 5% 0,25W
4001	4822 051 10008	0Ω 5% 0,25W
4002	4822 051 20008	0Ω JUMP. (0805)
4005	4822 051 10008	0Ω 5% 0,25W
4006	4822 051 10008	0Ω 5% 0,25W
4009	4822 051 10008	0Ω 5% 0,25W
4011	4822 051 10008	0Ω 5% 0,25W
4012	4822 051 10008	0Ω 5% 0,25W

COILS

5100	4822 157 62552	2,2μH
5250	4822 157 70601	DIG.OUT TRAF0

DIODES, TRANSISTORS & IC'S

6360	4822 130 30621	1N4148
6361	4822 130 30621	1N4148
6500	4822 130 31981	BZX79-C3V9
6740	4822 130 31983	BAT85
7100	4822 209 33339	SAA7345GP/M5
7300	4822 209 33252	TDA1549T/N1
7301	4822 209 83274	NJM4560D(CC45)
7301	4822 209 31153	NJM2114D(CC65)
7360	5322 130 42012	BC858
7361	5322 130 42012	BC858
7362	4822 130 42804	BC817-25
7363	4822 130 42804	BC817-25
7364	4822 130 42804	BC817-25
7365	4822 130 42804	BC817-25
7500	5322 130 42012	BC858
7501	5322 130 42012	BC858
7502	4822 209 80817	L7805CV
7600	4822 209 72587	TCA0372
7601	4822 130 83031	BPW85A
7700	4822 209 33695	MC68HC11ER32
7740	5322 130 42012	BC858
7741	4822 130 61207	BC848
7742	4822 130 61207	BC848

DISPLAY PANEL			KEYBOARD PANEL		
MISCELLANEOUS			1438	4822 276 13114	TACT SWITCH
1400	4822 256 91908	DISPLAY HOLDER	1439	4822 276 13114	TACT SWITCH
1402	4822 130 91388	DISPLAY CC45/65 MTZ	1440	4822 276 13213	TACT SWITCH
1420	4822 242 72527	RESONATOR 4MHz	1441	4822 276 13114	TACT SWITCH
1421	4822 276 13114	TACT SWITCH	1442	4822 276 13213	TACT SWITCH
1422	4822 276 13114	TACT SWITCH	1443	4822 276 13213	TACT SWITCH
1423	4822 276 13114	TACT SWITCH	1444	4822 276 13213	TACT SWITCH
1424	4822 276 13114	TACT SWITCH	1445	4822 276 13213	TACT SWITCH
1425	4822 276 13114	TACT SWITCH(CC65)	1446	4822 276 13213	TACT SWITCH
1426	4822 276 13114	TACT SWITCH(CC65)	1447	4822 276 13213	TACT SWITCH
1427	4822 276 13114	TACT SWITCH(CC65)	1448	4822 276 13114	TACT SWITCH
1428	4822 276 13114	TACT SWITCH(CC65)	1449	4822 276 13114	TACT SWITCH
1429	4822 276 13114	TACT SWITCH(CC65)	1450	4822 276 13114	TACT SWITCH
1430	4822 276 13114	TACT SWITCH(CC65)	6425	4822 130 30621	1N4148
1431	4822 276 13114	TACT SWITCH(CC65)	6426	4822 130 30621	1N4148
1432	4822 276 13114	TACT SWITCH(CC65)	6427	4822 130 30621	1N4148
1433	4822 276 13114	TACT SWITCH(CC65)	IR PANEL		
1434	4822 276 13114	TACT SWITCH(CC65)	2460	4822 126 11585	22nF +80-20% 25V
1435	4822 276 13114	TACT SWITCH(CC65)	3460	4822 116 52284	47k 5% 0,5W
1436	4822 276 13114	TACT SWITCH(CC65)	7460	4822 214 52009	GP1U58XP
1437	4822 276 13213	TACT SWITCH	HEADPHONE PANEL		
CAPACITORS			1371	4822 267 31453	HEADPHONE SOCKET
2402	5322 124 21643	22 μ F 20% 40V	2380	4822 126 11585	22nF +80-20% 25V
2404	5322 124 21643	22 μ F 20% 40V	2381	4822 121 51387	10nF 20% 16V
2405	4822 126 11585	22nF +80-20% 25V	2382	4822 121 51387	10nF 20% 16V
RESISTORS			2383	4822 126 12882	100nF +80-20% 50V
3400	4822 116 52258	220k 5% 0,5W	3380	4822 101 21199	10kX2 20% 0,025W
3401	4822 116 52257	22k 5% 0,5W	3381	4822 116 52233	10k 5% 0,5W
3402	4822 116 52257	22k 5% 0,5W	3382	4822 116 52233	10k 5% 0,5W
3403	4822 116 52257	22k 5% 0,5W	3383	4822 116 52244	15k 5% 0,5W
3404	4822 116 52257	22k 5% 0,5W	3384	4822 116 52244	15k 5% 0,5W
3406	4822 116 52257	22k 5% 0,5W	3385	4822 116 52206	120 Ω 5% 0,5W
3407 ▲	4822 052 10108	1 Ω 5% 0,33W	3386	4822 116 52206	120 Ω 5% 0,5W
3410	4822 116 52234	100k 5% 0,5W	7380	4822 209 82362	NJM4556D
3411	4822 116 52234	100k 5% 0,5W	MAINS VOLTAGE		
3412	4822 116 52175	100 Ω 5% 0,5W	5500 ▲	4822 146 31373	MAINS TRAF0 FOR CC45/02B/07B
3413	4822 116 52175	100 Ω 5% 0,5W	5500 ▲	4822 146 31374	MAINS TRAF0 FOR CC45/UBL
DIODES, TRANSISTORS & I.C.'s			5500 ▲	4822 146 31406	MAINS TRAF0 FOR CC65/02B/07B
6420	4822 130 30621	1N4148	5500 ▲	4822 146 31405	MAINS TRAF0 FOR CC65/UBL
6421	4822 130 30621	1N4148			
6422	4822 130 30621	1N4148			
6423	4822 130 30621	1N4148			
6424	4822 130 30621	1N4148			
7400	4822 209 30249	TMP47C212AN			
7401	4822 130 40938	BC548			
7402	4822 130 40938	BC548			