NOTE:
The indicated semiconductors are representative ones only. Other alternative semiconductors may be used and are listed in the parts list.



1 RESISTORS:
Indicated in Ω, ¼W, ½W, ±5% tolerance unless otherwise noted k : kΩ, M : MΩ, (F) : ±1%, (G) : ±2%, (K) : ±10% (M) : ±20% tolerance

2 CAPACITORS:
Indicated in capacity (μF)/voltage (V) unless otherwise noted p : pF
Indication without voltage is 50V except electrolytic capacitor

3 VOLTAGE CURRENT:
: Signal voltage at (95W+95W 4ohm) out (1KHz)
: DC voltage (V) at no input signal
Value in ( ) is DC voltage at rated power
: mA : DC current at no input signal

4 OTHERS:
: Signal route
The ⚠ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation

5. SWITCHES

TONE AMP ASSEMBLY
S301: TAPE 3 (ON–OFF)
S302: LOUDNESS (ON–OFF)

SPEAKER SWITCH ASSEMBLY
S401: SPEAKERS A, B (OFF–A–B–A+B)
PHONO AMP ASSEMBLY
S501: PHONO SEL. (MC–MM–MM SUB50)
INPUT SELECTOR ASSEMBLY
S701: FUNCTION SEL. (TA2–TA1–CD–PHONO–TUNER–LINE)
S702: REC. SEL. (2←1←2–SOURCE–OFF–CD–TUNER)
MAIN VOLUME ASSEMBLY
S801: DIRECT (ON–OFF)
S1 : POWER (ON–OFF)

The underlined indication the switch position

Line Voltage Selection

Line voltage can be changed with following steps.

1. Desconnect the AC power cord.
2. Remove the top cover.
3. Change the connection wire (To Power transformer) of Terminal No. 3 (WHITE) as follows.

Voltage	Terminal No. 3	Terminal No. 5
220V	Gray wire	.....
240V	.....	Gray wire