


TO FRONT PANEL PCB
POT, SIG, CLIP LED
SEE SH 3
6 PIN RIBBON

TO TRANSFORMER PCB
SEE SH 4
7 PIN RIBBON



POS STEP DRIVER

