

1	2	3	4	5	6	7	8	9
DD4 K561ЛA9	1	1	(0) 1	1	1	(0) 1	1	1
	2	0	0	0	0	1	1	1
	3	(0) 1	0	0	0	1	1	1
	4	1	1	1	1	1	1	1
	5	1	1	1	1	1	1	1
	6	1	1	1	1	1	1	1
	7	1	1	1	1	1	1	1
	8	1	1	1	1	1	1	1
	9	1	1	1	1	1	1	1
	10	1	1	1	1	1	1	1
	11	1	1	1	1	1	1	1
	12	1	1	1	1	1	1	1
	13	1	1	1	1	1	1	1
DD5 K561ЛA9	1	—	—	0	1	—	—	—
	2	0	0	1	1	0	0	0
	3	0	0	1	1	0	0	0
	4	0	0	1	1	0	0	0
	5	1	1	1	0	1	1	1
	6	1	1	1	1	1	1	1
	7	1	1	1	1	1	1	1
	8	1	1	1	1	1	1	1
	9	1	1	1	1	1	1	1
	10	1	0	1	0	1	1	1
	11	1	1	1	0	1	1	1
	12	1	1	1	1	1	1	1
	13	0	1	0	1	1	1	0
DD6 K561ЛA7	1	1	1	0	0	1	1	1
	2	1	1	1	1	1	1	1
	3	0	0	1	1	1	0	0
	4	0	0	1	1	1	0	0
	5	1	1	1	0	1	1	1
	6	1	1	1	0	1	1	1
	7	1	1	1	0	1	1	1
	8	1	1	1	0	1	1	1
	9	1	1	1	0	1	1	1
	10	0	0	1	1	0	0	0
	11	1	1	1	0	1	1	1
	12	1	1	1	1	0	0	0
	13	0	0	1	1	0	0	0

Примечание. Состоянию «0» соответствует напряжение 0...0,5 В, состоянию «1» соответствует напряжение 8...9 В, «—» соответствует произвольному состоянию, состояние () соответствует нажатой кнопке.

Напряжения, В

Транзи- стор	Вы- ход	Режим						после ⊗	после ⊗
		⊗	⊗	⊗	⊗	⊗	⊗		
VT1 KT3102B	Б	0	0	0	0	1,2	1,2	1,2	1,2
	К	25	25	25	25	1,2	1,2	1,2	1,2
VT2 KT3107B	Б	6,3	6,3	6,3	6,3	6,3	7,7	7,7	7,7
	К	6,0	6,0	6,0	6,0	6,0	~9	~9	~9
VT3 KT3107B	Б	9,0	9,0	9,0	4,5	9,0	9,0	9,0	9,0
	К	0	0	0	0,7	0	0	0	0
VT4 KT315T	Б	0	0	9	9	0	0	0	0
	К	9	9	8,3	8,3	9	9	9	9
VT5 KT315T	Б	-0,6	-0,6	-0,6	-0,5	-0,6	~6	~6	~6
	К	12	12	12	12	12	0	0	0
VT6 KT315T	Б	1,2	0	1,2	1,2	0	1,2	1,2	1,2
	К	0,5	15	0,5	0,5	15	0,5	0,5	0,5
VT7 KT315T	Б	0	9	9	9	9	0	0	0
	К	9	9	8,3	8,3	9	9	9	9
VT8 KT315T	Б	0	1,2	0	0	1,2	0	0	0
	К	12	1,2	12	12	1,2	12	12	12
	Б	0,6	0,6	0,6	0,6	0,6	0,6	0,6	0,6