


SA-6300

FP
FV
GN

PIONEER®

5-Line Voltage model



VR₁ MAIN VOLUME
VR₂ BALANCE CONTROL

VR₃ TREBLE
VR₄ BASS

SWITCHES

- S₁ FUNCTION
1. PHONO
2. TUNER
3. AUX

- S₂ TAPE MONITOR
OFF ↔ ON
S₃ LOUDNESS
OFF ↔ ON

S4 SPEAKER SELECTOR


1. OFF
2. A
3. B
4. A + B

S5 POWER SWITCH

- OFF ↔ ON


RESISTOR
IN C
OTH

CAPACITOR
IN C
P :



← A : DC CURRENT AT NO INPUT SIGNAL.

220V model



VR₁ MAIN VOLUME
VR₂ BALANCE CONTROL
VR₃ TREBLE CONTROL
VR₄ BASS CONTROL

SWITCHES

S₁ FUNCTION
1. PHONO
2. TUNER
3. AUX

S₂ TAPE MONITOR
OFF → ON
S₃ LOUDNESS
OFF → ON

S₄ SPEAKER SELECTOR

1. OFF
2. A
3. B
4. A + B

S₅ POWER SWITCH
OFF → ON

RESISTORS

IN OHM, 1/4W, ±5%
OTHERWISE NOTED

CAPACITORS

IN μF UNLESS NOTED
P : pF

