

DENON


Hi-Fi Integrated Stereo Amplifier

SERVICE MANUAL

MODEL PMA-1080R

INTEGRATED STEREO AMPLIFIER

H18392



CONTENTS

OPERATING INSTRUCTIONS	2-7
BLOCK AND LEVEL DIAGRAM	9
METHOD OF ADJUSTMENTS	9
REMOVAL OF EACH SECTION	10
SEMICONDUCTORS	11
PRINTED WIRING BOARD	12, 13
PRINTED WIRING BOARD PARTS LIST	14-17
WIRING DIAGRAM	18
EXPLODED VIEW OF CHASSIS AND CABINET	19
PARTS LIST OF EXPLODED VIEW	20
SCHEMATIC DIAGRAM	21,22

NIPPON COLUMBIA CO., LTD.

1

2

3


4

5

6

7


8







21









WARNING:
Parts marked with this symbol  have critical characteristics.
Use ONLY replacement parts recommended by the manufacturer.

CAUTION:
Before returning the unit to the customer, make sure you make either (1) a leakage current check or (2) a line to chassis resistance check. If the leakage current exceeds 0.5 milliamps, or if the resistance from chassis to either side of the power cord is less than 240 kohms, the unit is defective.

WARNING:
DO NOT return the unit to the customer until the problem is located and corrected.

NOTES:
Circuit and parts are subject to change without prior notice.





NOTE:
— +B LINE
--- -B LINE
--- SIGNAL LINE

